




OPERATOR'S MANUAL

OPERATION
MAINTENANCE
LUBRICATION

MCCORMICK®
FARMALL®

CUB®
Tractor



TO THE OWNER

We are glad to welcome you as an owner of a product of International Harvester Company. You have a fine product, designed and built to give you many years of efficient operation. The way you operate and the care you give this product will have much to do with its successful performance.

To help you operate your equipment with utmost efficiency we have provided this operator's manual. It has been carefully prepared to give you the benefit of many years of experience gained in field testing and normal usage of this and similar products.

We urge you to study this manual so you will understand your new equipment thoroughly before operating it. We also urge you to take care of your manual so you will have it available for reference when you need it.

If your manual is lost or destroyed, a new copy may be ordered from the International Harvester dealer at a nominal price. Your International Harvester dealer will also be glad to answer any questions you may have on the operation or care of this product.

It is the policy of International Harvester Company to improve its products whenever it is possible and practical to do so. We reserve the right to make changes or add improvements at any time without incurring any obligation to make such changes on products sold previously.

All illustrations and descriptive matter in this publication apply to International Harvester products sold under the International, McCormick, or McCormick-International trade name.

As a member of the National Safety Council, we are privileged to use the Green Cross for Safety to designate not only our interest in Safety, but to point out more clearly the safety precautions in this manual.

Parts Depots are strategically located at 12 points and Transfer Houses at 4 points in the United States. Ample stocks are maintained at all times to assure prompt shipment to your IH dealer to meet your requirements.

Parts Depots in the United States

Albany 1, N. Y.	Broadview, Ill.	Denver 17, Colo.	Portland 8, Oreg.
Atlanta, Ga.	Columbus 16, Ohio	Kansas City 17, Kans.	Richmond 4, Calif.
(East Point, Ga.)	Dallas 22, Tex.	Memphis 6, Tenn.	St. Paul 4, Minn.
Baltimore 3, Md.			

Transfer Houses in the United States

Broadview, Ill.	Kansas City 17, Kans.	St. Paul 14, Minn.
	Memphis 6, Tenn.	

District Offices in Canada

Calgary, Alta.	Montreal 14, Que.	Regina, Sask.	Toronto, Ont.
Edmonton, Alta.	Quebec 8, Que.	Saint John, N. B.	Vancouver 4, B. C.
London, Ont.		Saskatoon, Sask.	Winnipeg 10, Man.

8-30-62.

International Harvester Sales and Service is maintained in all principal countries of the world.

Export address: International Harvester Export Company, Chicago 1, Illinois, U. S. A.

Canadian address: International Harvester Company of Canada, Ltd., Hamilton, Ont., Canada

INDUSTRIAL

INTERNATIONAL HARVESTER DELIVERY REGISTRATION

OWNER'S COPY

Purchaser B. ZIEGLER
Address Route 20
City Perry State Ohio
Equipment location Lake Ohio
(County and State)

Dealer MENYOR MOTORSALES
Address _____
City MENYOR State Ohio

~~INDUSTRIAL~~ Agricultural Tractor and/or Equipment _____ (A-1)
Model Farmall Cub Serial No. 2236975 Date of delivery 5/26/64 (8-10)
Size _____ Engine No. _____ No. of similar units owned
(including new purchase) _____ (11-12)

Trade-In Equipment Similar To Above

☒ IH (1) ☐ M-E (6) ☐ New Idea (A) Model Cub
☐ Deere (3) ☐ Oliver (8) ☐ New Holland (B)
☐ Ford (7) ☐ A-C (2) ☐ Other _____ (9) Age in years 15 (14-15)
☐ Case (4) ☐ M-M (5) (Col. 13) (Make)

Other New Equipment Included On Same Order (Not Requiring Separate Delivery Registration)

Machine _____	Machine _____	Machine _____
Model _____	Model _____	Model _____
Serial No. _____	Serial No. _____	Serial No. _____
Size _____	Size _____	Size _____

Market Information

Chief Source Of Farm Income (Check only one)

☐ Cash grain (51) ☐ Vegetable (54) ☐ Dairy (57) ☐ General (59)
☐ Tobacco (52) ☐ Fruit-nut (55) ☐ Livestock (58)
☐ Cotton (53) ☐ Poultry (56) (Col. 40-41) ☒ Other NURSERY (60)
(Description)

Total Acres All Crops Harvested Last Year (Check only one)

☐ Under 50 (1) ☐ 100-179 (3) ☐ 260-499 (5) ☐ 1000 and over (7)
☐ 50-99 (2) ☐ 180-259 (4) ☐ 500-999 (6)
(Col. 42)

Estimated Part Of Time New Machine Will Be Used For Custom Work (Check only one)

☐ None (1) ☐ 25% (2) ☐ 50% (3) ☐ 75% (4) ☐ 100% (5)
(Col. 43)

The above equipment was carefully inspected and adjusted in accordance with factory specifications before delivery.

Purchaser has been instructed in the proper and safe operation of this equipment, in addition to the necessary maintenance procedures. An Operator's Manual has been delivered to him.

Dealer Menyor Motor Sales
By M. Menyor Date 5/26/64

The operation and servicing procedures for this equipment have been explained to me, and a copy of the Operator's Manual has been received.

Customer R. Ziegler
Date 5/26/64


DISTRICT OFFICE USE ONLY

Dealer No. 17-24	State 44-45	County 46-48	Kind 49-51	Code 52-55	Kinds Sold With Basic Machine 57-59 60-62 63-65	Note Number 71-79
---------------------	----------------	-----------------	---------------	---------------	--	----------------------

CONTENTS

Description	Page No.
DELIVERY REGISTRATION	1
CONTENTS	2 to 4
INTRODUCTION	4 to 6
INSTRUMENTS AND CONTROLS	7
BEFORE STARTING THE TRACTOR	8
PREPARING FOR EACH DAY'S WORK	9, 10
GASOLINE ENGINE	10, 11
GASOLINE FUEL SYSTEM	11, 12
DRIVING THE TRACTOR	13, 14
TOUCH-CONTROL SYSTEM	14 to 16
FAST-HITCH	17
HITCHING TRAILING EQUIPMENT TO THE TRACTOR	18, 19
BELT PULLEY AND POWER TAKE-OFF	20 to 23
COOLING SYSTEM	23, 24
AIR CLEANING SYSTEM	24 to 36
ELECTRICAL SYSTEM	37, 38
MINOR ENGINE SERVICE OPERATIONS	39, 40
FRONT WHEELS	41, 42
REAR WHEELS	43, 44
WEIGHTS	45, 46
PNEUMATIC TIRES	46, 47
BRAKES	47, 48
CLUTCH	48, 49
STORING THE TRACTOR	50
COLD WEATHER PRECAUTIONS	51 to 55
TROUBLE SHOOTING	55 to 59
LUBRICATION	60
LUBRICATION TABLE	61 to 65
LUBRICATION GUIDE	66, 67
SPECIFICATIONS	68
EXTRA EQUIPMENT AND ACCESSORIES	69, 70
INDEX	

INTRODUCTION



B-12884

Illust. 2
Farmall Cub Tractor.

INTRODUCTION

Assembled in this manual are operation, lubrication, and maintenance instructions for Farmall Cub Tractors. This material has been prepared in detail in the hope that it will help you to better understand the correct care and efficient operation of the tractor.

Your International Harvester dealer has factory-trained servicemen, modern tools, and IH service parts to assure you of satisfactory tractor operation. To get the most out of the tractor, and to assure economical operation and top performance, the tractor should be inspected periodically by your International Harvester dealer.

Depending upon your use of the tractor, these inspections should be performed as needed, or at least once a year, at which time a tune-up or other necessary service work should be performed. Proper pre-season maintenance will assure you of minimum lost time when your tractor is most needed.


Dealers are kept informed on the latest methods of servicing tractors. They carry stocks of IH parts, and are backed in every case by the full facilities of a nearby International Harvester district office and parts depot.

In order to provide a tractor equipped as nearly as possible to suit each customer's needs, a variety of extra equipment and accessories is available. See your International Harvester dealer.

Where operating and maintaining instruction on these items is required, it is included in the instructions for operating or maintaining the tractor. Disregard the instructions for equipment not on your tractor.

The illustrations in this manual are numbered to correspond with pages on which they appear; for example, Illusts. 3 and 3A are on page 3.


Throughout this manual the use of the terms LEFT, RIGHT, FRONT, and REAR must be understood to avoid confusion when following instructions. LEFT and RIGHT indicate the left and right sides of the tractor when facing



Illust. 3
Terms of location.


forward in the driver's seat. Reference to FRONT indicates the radiator end of the tractor; to REAR; the hitch end. See Illust. 3.

When in need of parts, always specify the tractor and engine serial numbers including prefix and suffix letters. The tractor serial number is stamped on a name plate attached to the right side of the clutch housing. See Illust. 3A.



Illust. 3A
Location of the tractor serial number.

INTRODUCTION




The engine serial number is stamped on the left side of the engine crankcase to the right of the carburetor. This serial number is preceded by the letters FCUBM. See Illust. 4.

For ready reference, we suggest that you write these serial numbers in the spaces provided on the Delivery Registration.

Illust. 4

Location of engine serial number.

INSTRUMENTS AND CONTROLS



Illust. 4A

Controls on the Farmall Cub Tractor.

INSTRUMENTS AND CONTROLS

BRAKE PEDALS

These pedals are used to stop the tractor, to hold the tractor in a stationary position, or to assist in making sharp turns.

The brake pedal latch (behind the left brake pedal) is used to latch both brake pedals together, causing the brakes to operate simultaneously.

To stop the tractor, latch the pedals together so both brakes will operate simultaneously when the pedals are pressed down.

To hold the tractor in a stationary position, latch the pedals together, depress and lock them in this depressed position by using the brake pedal lock.

To assist in making a sharp turn, the pedals must be operated individually, depressing the pedal on the side toward which the turn is to be made.




Caution! Always latch the brake pedals together when driving the tractor in high gear. To latch the pedals together, engage the latch (located in back of the left pedal) (Illust. 4) in the slot in back of the right pedal. When the brake pedals are not latched together, the latch should rest in the slot in back of the left brake pedal.

The brake pedal lock (Illusts. 4A and 12) is used to lock the brake pedals in the depressed position. This prevents the tractor from moving.

CLUTCH PEDAL

This pedal, when depressed all the way, disengages the engine from the transmission.

GEARSHIFT LEVER



A-14822

Illust. 5
Gear shifting positions.

This lever is used to select various gear ratios provided in the transmission. There are three forward speeds and one reverse speed. See Illust. 5. Refer to "Specifications" on page 66.

CHOKE ROD

The choke rod makes possible the regulation of the carburetor choke from the driver's seat. Pulling out on the choke rod closes the carburetor choke for starting the engine; pushing it back in opens the choke.


CARBURETOR CHOKE LEVER

The carburetor choke lever controls the air supply to the carburetor. When the choke lever (Illusts. 4 and 9A) is moved up all the way (closed position) the air supply is cut off, thereby enriching the fuel mixture for starting the engine. If your tractor is not equipped with a cranking motor and choke rod, move the choke lever up all the way before cranking the engine. Moving the choke lever back down opens the choke for normal engine operation.

ENGINE SPEED CONTROL LEVER

This lever controls the speed of the engine and, when set in a given position, will maintain a uniform engine speed even though the engine load may vary.

Do not permit the engine to run below the minimum idle speed for any length of time, or operate the engine at more than the regular, governed speed. Excessive speed is harmful. Refer to the "Specifications" on page 66.



A-14742

Illust. 5A
Various positions of the engine speed control lever.

INSTRUMENTS AND CONTROLS

GOVERNOR

The governor is set at the factory and should require no adjustment. Consult your International Harvester dealer if the governor does not function properly.

IGNITION SWITCH BUTTON

This button closes and opens the electrical circuit for operating and stopping the engine. Pull the button out for operating and push it in to stop the engine.

Caution! On tractors with battery ignition, when the engine is not operating or the engine has stalled and the operator leaves the tractor, the ignition switch button must be pushed all the way in, so that the switch is in the "Off" position, to prevent battery discharge.

STARTING SWITCH CONTROL ROD

To start the engine, adjust the choke rod and pull out on the starting switch control rod as explained on pages 9 and 10.

LIGHTING SWITCH


The switch has four positions: "Off" position; "D" position for dim headlights, bright instrument lights, and a red taillight; "B" position for bright headlights, instrument lights, and a red taillight; and "R" position for bright headlights, instrument lights, and a white rear light. The red taillight should always be used when traveling on the highway at night or during times of poor visibility. The white rear light is for field use only and should not be used on the highway.

BELT PULLEY AND POWER TAKE-OFF SHIFTER ROD


The shifter rod is used to engage or disengage the belt pulley or the power take-off. Refer to pages 18 and 19 for operating instructions.

OIL PRESSURE GAUGE

This gauge (Illusts. 6 and 6A) indicates whether lubricating oil is circulating through the engine. The indicator needle should be past the first mark above 0 when the engine is running at speeds approximately 100 r.p.m. above slow idle speed. If the needle does not move past the first mark above 0, stop the engine immediately and investigate the cause of the oil pressure failure. If you are unable to find the cause, consult your International Harvester dealer before operating the engine.




Illust. 6
Location of oil pressure gauge.



Illust. 6A
Oil pressure gauge.

CHARGE INDICATOR


This instrument indicates whether the generator is charging or the battery is discharging. If it shows discharge continuously, investigate the cause to avoid completely discharging the battery and possible damage to the generator. Refer to pages 32 and 33 for additional information.



Illust. 6B
Charge indicator.

BEFORE STARTING THE TRACTOR

LUBRICATION



Illust. 7
Crankcase breather and oil level gauge.

Lubricate the entire tractor, using the "Lubrication Guide."

Check the oil levels of the engine crankcase, air cleaner, transmission, belt pulley housing and all gear cases to see that they are filled to the correct levels with oil of the proper viscosity for the prevailing temperature. Refer to "Lubrication Guide" on pages 63 to 65.

Tractors packed for export have all oil drained from the engine crankcase, air cleaner and all gear cases.

PNEUMATIC TIRES

Before moving the tractor, check the air pressure in the pneumatic tires and inflate or deflate the front tires to twenty pounds and the rear tires to twelve pounds. Refer to the tables on pages 45 and 46 for more complete information.

ENGINE COOLING SYSTEM

Be sure the drain plug underneath the radiator is closed. See Illust. 21.

Tractors shipped to destinations in the United States and Canada have the cooling system filled with antifreeze solution. Check the coolant level in the radiator. When cold, the coolant level should be slightly below the bottom of the filler neck.

If water is added, use only clean water; soft or rain water is recommended, as it does not contain alkali, which forms scale and eventually clogs the passages.

Never start or operate the engine without water or antifreeze solution in the cooling system.

For further information, see "Cooling System" on pages 20 to 23. If the tractor is to be operated in freezing temperatures, refer to "Cold Weather Precautions" on page 50.

FUEL SYSTEM

International Harvester gasoline burning engines are specifically designed for use with regular grade gasoline having a 90 minimum octane rating — Research Method (approximately 84 Motor Method).

Use clean fuel and keep it clean. Store fuel in tanks equipped with hose and nozzle to prevent contamination of the fuel. The use of funnels, cans, and drums is not desirable because they are difficult to keep clean.


INSTRUMENTS AND CONTROLS

Thoroughly acquaint yourself with all instruments and controls as described on pages 4 to 6.

PREPARING FOR EACH DAY'S WORK

Air cleaner cap..... Remove any dirt or chaff.
 Air cleaner oil cup..... Remove, clean and refill. See the "Lubrication Guide."
 Lubrication points See "Lubrication Guide."
 Cooling system Check the level of the coolant in the radiator.

FILLING THE FUEL TANK




Illust. 8
Filling the fuel tank.


Fill the fuel tank with a good grade of clean gasoline, preferably at the end of each day's run. This will force out any moisture-laden air and prevent condensation in the fuel tank.



Safety First! Never remove the fuel tank cap or fill the fuel tank when the engine is running, is hot, or near an open flame. Do not smoke or use an oil lantern when working around inflammable fuels. When pouring fuel, keep the hose and nozzle or the funnel and container in contact with the metal



Never refuel the tractor while the engine is running or extremely hot.



Illust. 8A
Vent holes in filler cap.

of the fuel tank to avoid the possibility of an electric spark igniting the fuel. Do not light matches near inflammable fuels, as the air within a radius of several feet is mixed with a highly explosive vapor.

The fuel tank filler cap has air vents. See Illust. 8A. Keep these vents open at all times to assure proper flow of the fuel.

AIR CLEANER OIL CUP

The air cleaner cap should be cleaned, and the oil in the air cleaner oil cup should be changed more frequently than every ten hours of operation, if unusually dusty and dirty conditions are encountered.




Illust. 8B
Oil level bead in air cleaner oil cup.

GASOLINE ENGINE

Before attempting to start or operate the tractor, be sure you review the instructions for the new tractor and thoroughly familiarize yourself with the instruments and controls.

This engine is designed to operate on gasoline with a 90 minimum octane rating (Research Method).

FUEL SYSTEM



Illust. 9
Fuel system and controls.

Be sure the shut-off valve on the fuel strainer under the gasoline tank is open. To prevent leakage or seepage when the valve is in its full-open position, screw out the needle stem (shut-off valve) until the seat on the stem is tight against the stop.

STARTING THE ENGINE

1. Put the gearshift lever in the neutral position. See Illust. 5.

2. Pull the choke rod all the way out. See Illust. 4.

Avoid overchoking, as excessive use of the choke will flood the engine, making it hard to start. The use of the choke for starting will vary, depending on temperature and altitude.

3. Advance the engine speed control lever one third. See Illust. 5A.


4. Pull out on the ignition switch button. See Illust. 4.



When starting the engine in a barn or garage, keep the doors wide open because exhaust gases from internal-combustion engines contain poisonous carbon monoxide which is odorless, tasteless and colorless.

5. Disengage the engine clutch by pressing down on the clutch pedal. See Illust. 4.

6. Pull out on the starting switch control rod (Illust. 4) and release it as soon as the engine starts. However, do not operate the cranking motor for more than 30 seconds at any one time. If the engine does not start within this time, release the starting switch control rod and wait a minute or two; then try again.



Illust. 9A
Closing the carburetor choke lever.
(Tractors without cranking motor).

GASOLINE ENGINE

STARTING THE ENGINE - Continued

Note: Never operate the cranking motor while the engine is rotating.

7. Slowly release the clutch after the engine starts.



Caution! When hand cranking the engine, be sure that the gearshift lever is in the neutral position. Always stand in a position that will eliminate any possibility of being struck by the starting crank, if there is a reversal of the direction of the engine. Crank the engine by using quick up-strokes; do not spin it.

AFTER THE ENGINE STARTS

As soon as the engine starts, adjust the choke to a point where the engine operates without missing, and as the engine warms up, open the choke by gradually pushing the choke rod all the way in, or by moving the carburetor choke lever down all the way. See **Illustrations 9 and 9A**. Do not use the choke to enrich the fuel mixture, except when starting the engine.

Immediately after the engine starts, check the oil pressure gauge (**Illustration 6A**) to see whether lubricating oil is circulating through the engine. If it is not, stop the engine and inspect the oil system to find the cause of failure. If you are unable to find the cause, be sure to consult your International Harvester dealer before operating the engine.

STOPPING THE ENGINE

Retard the engine speed control lever by pulling it all the way back (**Illustration 4**). Allow the engine to cool slowly from full-load operation by slowly idling the engine for a short time. Then push the ignition switch control button all the way in to stop the engine. It is advisable to close the gasoline shut-off valve if the engine is to be stopped for any length of time.

GASOLINE FUEL SYSTEM

Note: Unusual operating conditions, or fuel octanes below those recommended, may require modification of the specified ignition timing (shown in "Specifications") to a retarded position. Retard from the specified setting as required, approximately one degree for each octane below 90, to eliminate knock (not more than 6 degrees). It is recommended that this be done by an International Harvester dealer.

CLEANING THE FUEL STRAINER AND SEDIMENT BOWL

Clean the fuel strainer after every 250 hours of operation. To do this, proceed as follows:

1. Close all shut-off valves.
2. Take the strainer apart by loosening the nut under the sediment bowl.
3. Clean the sediment bowl and clean the screen if necessary.
4. When reassembling, be sure the cork gasket between the bowl and the main body is

in good condition and does not leak. Use a new gasket if necessary.




Illustration 10

Fuel strainer showing the glass bowl removed for cleaning.

GASOLINE FUEL SYSTEM

CARBURETOR

Use clean fuel; the presence of dirt and water will disturb the functioning of the carburetor. Clean the fuel screen after every 500 hours of operation.

The fuel screen can be removed for cleaning by unscrewing the fuel line fitting and removing the elbow; clean the screen and replace it.


The flange nuts which hold the carburetor to the manifold should be checked periodically for tightness. See "A", Illust. 11.

Occasionally check cover screws which fasten the fuel bowl to the fuel bowl cover. See "B" Illust. 11. They should be kept tight to avoid any air leakage past the fuel bowl cover gasket.

The engine and carburetor are correctly set when shipped from the factory. If this setting has been disturbed for any reason, proceed as follows:

Adjusting the Idle Adjusting Screw

Close the idle adjusting screw to its seat by turning it to the right (or in); then open it one turn. Start the engine and operate it at fast idling speed (without any load) until thoroughly warm. Cover the radiator if necessary or close the radiator shutter if the tractor is so equipped.




Illust. 11
Carburetor adjustment.

While the engine is running at fast idle speed, it is advisable to screw in the throttle stop screw a few turns to prevent the engine from stopping when the throttle is closed. Now close the throttle. The engine will then be idling at a fairly high speed and the throttle stop screw can be backed out a little at a time until the desired idle speed is obtained.

If the engine misses or rolls while backing out the throttle stop screw, the idle adjusting screw may be adjusted either in or out until the engine operates smoothly. Speed up the engine for a few seconds; then recheck the idle adjustment. A slight adjustment in or out will give the smoothest idle.

DRIVING THE TRACTOR



Illust. 11A
Seat in the forward position.

ADJUSTING THE SEAT

The tractor seat can be set in either of two positions by removing the tool box and changing the position of the two cap screws in the seat post base (Illust. 11A), giving a total adjustment of 1-1/2 inches. Tighten the cap screws securely when reassembling and replace the tool box.

STARTING THE TRACTOR

1. Advance the engine speed control lever slightly. See Illust. 5A.
2. Disengage the clutch by pressing the clutch pedal all the way down.
3. Hold the clutch pedal in this position and move the gearshift lever to the desired speed.

DRIVING THE TRACTOR

STARTING THE TRACTOR - Continued

4. Start the tractor in motion by slowly releasing the clutch pedal and advancing the engine speed control lever to the position where the engine operates best for the load to be handled. **Note:** Do not shift gears while the engine clutch is engaged or while the tractor is in motion.

5. Do not rest your feet on the clutch or brake pedals while driving the tractor, as this will result in excessive wear on the linings.

Always latch the brake pedals together before driving the tractor in high gear. To latch the pedals together, engage the latch (located in the back of the left brake pedal) in the slot in the back of the right pedal. See *Illust. 12*. When the brake pedals are not latched together, the latch should rest in the slot in the back of the left brake pedal. See *Illust. 12*.

STEERING THE TRACTOR

The tractor is steered in the conventional manner by means of the steering wheel; however, to make a sharp or pivot turn, press either the right or left brake pedal, depending on the direction in which the turn is to be made. The brake pedals must be unlatched so they can be operated individually.

TOWING THE TRACTOR

When towing is necessary, use a rope, chain, or cable and have an operator steer the tractor and operate the brakes.


Attach a tow rope, chain, or cable around the front axle and steering gear housing. When towing a tractor, do not exceed a speed of twenty miles per hour.

STOPPING THE TRACTOR

Disengage the clutch by pressing down firmly on the clutch pedal, and move the gear-shift lever to the neutral position. Use the brakes if necessary.


LOCKING THE BRAKES

Always lock the brakes when the tractor is parked on a grade or when doing belt work. To




Illust. 12
Brake pedals latched together and lock engaged to hold tractor in a stationary position.

lock the brakes, first latch the brake pedals together with the latch as previously described. Now press down on the foot pedals; then place the brake pedal lock in the engaged position as shown in *Illust. 12*. To disengage the lock, press down on the foot pedals and lift the lock out and place it in the disengaged position, against the right brake pedal.



TOUCH-CONTROL SYSTEM



Illust. 13
Touch-Control system.

The Touch-Control system is ready to operate whenever the engine is running. You will receive the maximum of satisfactory service by closely adhering to the following simple precautions and service operations.

The importance of keeping the system free from all dirt, grit, and other foreign matter cannot be stressed too strongly. Keep the Touch-Control fluid reservoir, pipe lines, and pump as clean as possible at all times. The same care must be given to the cylinder, hose lines, and connections. As an added precaution against the entry of dirt into the system, the reservoir is constructed without an air vent. Sufficient air space is allowed above the fluid level to compensate for the pressure changes occurring during the operation of the system. As a result a small amount of pressure may be found in the reservoir upon removing the filler plug when checking the fluid level.

Note: Always keep the Touch-Control lever or levers in the rearward position (toward tractor seat) when the tractor or the Touch-Control system is not being actively used. This places the piston in the retracted position, preventing exposure to any moisture which may have condensed in the leather dust boot.

The control lever (Illust. 13) gives the operator complete, instantaneous and effortless control of all the direct-connected equipment operating adjustments. The use of the lever will depend on the type of equipment mounted on or pulled by the tractor. Complete instructions for operating the lever are included in the Owner's or Operator's Manual furnished with the implement. General instructions for operating the lever are given below.

The control lever quadrant is provided with a pair of adjustable Touch-Control lever stops.

The front stop when set in a given position will limit the travel of the control lever and prevent the equipment from being raised above the desired height.

The rear stop is used to point out the position where the control lever should be each time the equipment is lowered to maintain a uniform working depth.

To lower the equipment, move the control lever back until the equipment has reached the desired working depth; then move the rear stop to this position and tighten in place.

TOUCH-CONTROL SYSTEM

The working depth will be maintained by moving the lever back to the stop each time the implement is lowered.

After attaching the implement to the tractor, the Touch-Control lever front stop must be properly set if there is a possibility of the implement not clearing the underside of the tractor. Once the stop is set, the implement can be raised quickly by a flick forward on the control lever.

To set the Touch-Control stop, slowly move the control lever forward to raise the implement and stop it before the implement hits any part of the underside of the tractor. Then move the stop up against the control lever and tighten it in this position. This will prevent the control lever from being moved past the point of the desired lifting height.

Note: If the implement hits the underside of the tractor, in addition to doing possible damage to the tractor or implement, the Touch-Control system will not have completed its cycle and this will cause the pump unit to operate at maximum high pressure and heat the IH Hy-Tran® fluid excessively, thereby causing possible internal damage to the pump. This condition can be quickly detected by a noticeable loading of the engine.

If this condition should occur, immediately move the control lever back and set the con-

trol lever stop at a point where the raised implement will not hit the underside of the tractor.

AIR IN THE SYSTEM

Make certain that all connections and openings are well sealed. The entire system must be kept tightly sealed at all times, not only to prevent loss of fluid but also to avoid entrance of air in the inlet end of the system. Air entering the system interferes with proper lubrication of moving parts. It causes an increased amount of vibration and an unsteady pressure. Presence of air in the system will be noticed by a noise in the pump or by the pump laboring when operating under high pressure. Proper filling of the reservoir and working the system during the filling process, will work the air out of the system.

Freeing the System of Trapped Air

Start the tractor engine and operate it at a moderate idle speed. With the filler plug removed, move the Touch-Control lever or levers back and forth 10 to 12 times through its full range of travel. This quickly frees the system of trapped air. Then with the control lever in the rearward position (toward tractor seat), stop the engine.

If necessary, add sufficient clean fluid to the reservoir to bring the fluid level to within 1/2-inch of the bottom of the filler opening. Replace and tighten the filler plug.

FAST-HITCH

Touch-Control raises and lowers the complete hitch, thus raising the equipment to the transport position, or lowering it to the working position.

The leveling crank at the rear of the tractor controls leveling, and the depth adjusting crank on the right side controls depth adjustment.


When operating the hitch in other than the fixed drawbar position, the belt pulley must be removed. The belt pulley shaft must be covered with the belt pulley shaft guard and the power take-off shaft must be covered with the power take-off shaft guard, if not already so protected.

Note: Refer to page 13 for additional information regarding the Touch-Control system.

Note: The following operating and adjusting instructions are general only. Refer to the implement Operator's Manual for specific instructions.

The Touch-Control hand lever serves to control the raising and lowering of equipment. Do not attempt to gauge the depth with this lever unless so instructed in the equipment manual. Plows must be free to float up and down and to seek their own level as determined by the hitch setting. The depth adjusting crank (Illust. 15) serves to control the working depth of plows and various other equipment. The leveling crank controls leveling as required for plowing when opening up a furrow or for a change in plowing depth. The diagonal link permits the plow to swing from side to side, when the lock bolt is loose so the diagonal link is free to swing.

FAST-HITCH



Illust. 15
Rear view of Farmall Cub Tractor with Fast-Hitch.

FAST-HITCH

COUPLING THE EQUIPMENT

Adjust the height of the hitch socket with the Touch-Control and level the hitch with the leveling crank so the prong of the equipment can enter the hitch socket when the tractor is backed against the equipment (Illust. 15). The latch snaps shut when the prong reaches the proper position.

To uncouple the equipment on ground level, lower the equipment to the ground, reach back and lift the hitch latch (Illust. 15) with the forefinger. If the latch is difficult to disengage, back the tractor slightly against the equipment to relieve the strain on the latch. The latch will remain open until the equipment prong is withdrawn.

HITCH ADJUSTMENTS

The height of the hitch determines the working depth of the equipment. The depth adjusting crank (Illust. 15) raises and lowers the front end of the pull bar to reach the desired working depth called for in the instructions in your equipment manual.

PULL BAR EXTENSION

A pull bar extension is available for pulling trailing-type equipment. When in use, the extension is attached to the pull bar with the hitch hole toward the rear. It is held in place by a pivot pin and a quick attachable cotter pin. When not in use, the pull bar extension should be turned with the hitch hole toward the front. See Illust. 15.

When plowing, the lock bolt (or hand screw) on the diagonal link must be loose or unscrewed far enough so that the diagonal link is free so the plow can swing from side to side. Additional lateral swing can be obtained

when required, by removing the quick-attachable cotter pin "A" (Illust. 15) from the pull bar support.

When operating with middlebusters or cultivators, the lock bolt must be screwed in tightly to keep the unit in a rigid position to prevent the equipment from swinging.

When cultivating crops with high foliage, turn the depth adjusting crank so the hitch bail is set at its highest position. If necessary the Fast-Hitch pull bar and diagonal links may be removed to provide more clearance under the tractor.

FAST-HITCH LOAD LIMITATIONS

Caution! Do not overload the rear axle or the Fast-Hitch components with the equipment or accessories.

The transport loads listed below are considered satisfactory for Fast-Hitch operation. The equipment weights shown in the following examples do not include any allowance for additional weights on the equipment.

a. Five-foot disk harrow with ten 20-inch disks—360 pounds—use a rear wheel tread setting up to 56-inches.

b. Rotary hoe—355 pounds—use a rear wheel tread setting up to 56-inches.

c. Utility carrier.

With a 400 pound payload in the center of the platform—use a rear wheel tread setting up to 56-inches.

In general, the loads must decrease as the tread settings increase, and the loads must decrease as the distance from the rear axle to the center of gravity of the load increases.

HITCHING TRAILING EQUIPMENT TO THE TRACTOR


Do not attempt to pull when the drawbar is removed.
Drawbar bolts must be kept tight.
All hitches for trailing implements must be attached to the drawbar.

The tractor exerts its pulling power on trailing-type equipment by means of the drawbar, which is adjustable up and down to accommodate different hitches. Proper hitching will save both the tractor and the equipment it is pulling from undue strains. Hitch so the center line of pull of the tractor will fall in line with, or at least near, the center line of draft of the trailing equipment. Hitching to one side or the other of the line of draft will cause stresses and strains on both the tractor and the equipment being pulled, frequently great enough to do permanent damage. Incorrect hitching will also tend to make the tractor difficult to steer and will result in unsatisfactory work by the equipment being pulled.

When using a long chain to hitch the tractor to the load, drive the tractor forward slowly until all of the slack is taken out of the chain.

REMOVING THE DRAWBAR

The quick-attachable drawbar can be easily removed. To remove the drawbar, loosen the bolts "A" (Illust. 17) and unhook the complete drawbar. The drawbar can be reversed and placed in the forward position when so desired.



Illust. 17
Removing the drawbar.




A-12895

When the tractor is pulling power equipment, be sure that all power line shielding is in place and in good order.

ADJUSTING THE DRAWBAR


The drawbar can be set at three different heights to obtain the proper hitch position.

To raise or lower the drawbar, remove bolts "B" (Illust. 17A), and raise or lower the drawbar to the upper or lower hole in the drawbar bracket. Replace bolts "B" and tighten securely.



Illust. 17A
Drawbar adjustment.


BELT-PULLEY AND POWER TAKE-OFF



Don't put on or remove the belt from the belt pulley while the pulley is in motion.

If your tractor is equipped with a belt pulley or power take-off, the following instructions and precautions should be carefully studied and followed.

The belt pulley and power take-off are started and stopped by the same engine clutch as the tractor. Be sure to disengage the engine clutch before moving the belt pulley or power take-off shifter rod. The belt pulley is driven by the power take-off shaft; therefore, the same shifter rod is used to operate either the belt pulley or power take-off. The shifter rod should always be in the disengaged (forward)



Always stop the power take-off before dismounting from the tractor.

position when the belt pulley or power take-off is not in use.

OPERATING THE BELT PULLEY OR POWER TAKE-OFF WITH THE TRACTOR STANDING STILL

1. The transmission gearshift lever must be in the neutral position.
2. Move the engine speed control lever back to low idle speed.
3. Depress the clutch pedal to disengage the engine clutch.
4. Press down on the shifter rod and move it back to the engaged position; release the shifter rod and allow it to lock in place.
5. Slowly release the clutch pedal.
6. Observe the following instructions when using the tractor belt pulley:
 1. Secure the equipment to receive power in the desired location.
 2. Align the tractor belt pulley with the equipment pulley. Keep the tractor level if possible.
 3. Observe the direction of belt travel indicated on the belt, and install the belt accordingly to prevent damaging it.
 4. Tighten the belt enough to prevent the belt from rubbing against itself during operation. Do this by driving the tractor into the belt, locking the brakes, and blocking the tractor rear wheels. (When using a very long belt or a crossed belt, it will not be possible to eliminate all rubbing).
 5. Gradually bring the tractor engine up to speed, making sure the belt is running true.

Note: Static electricity, generated by belt work, can be discharged harmlessly from tractors with pneumatic tires, by attaching a chain to the tractor and allowing it to touch the ground.

For belt and pulley speeds, refer to page 67.

BELT-PULLEY AND POWER TAKE-OFF

OPERATING THE POWER TAKE-OFF WITH TRACTOR IN MOTION

Follow the first four steps outlined above; then release the power take-off shifter rod and allow it to lock in place. Keep your foot pressed down on the clutch pedal (in the disengaged position), advance the engine speed control lever and move the transmission gear-shift lever to the speed that is desired to run the tractor. Slowly release the clutch pedal. This will start the tractor in motion with the power take-off in operation.




Caution! When operating power take-off driven machines not equipped with an over-running clutch (such as a rotary brush cutter), the following precautions should be taken:

Slow down when approaching trees, fences, or ditches. Flywheel effect of the driven machine will drive the tractor forward after the engine clutch is disengaged. To stop the forward travel more quickly, retard the engine speed control lever, disengage the engine clutch, move the gear shift lever to the neutral position, and apply tractor brakes.

CHANGING FROM BELT PULLEY TO POWER TAKE-OFF

Remove two 3/8 N. C. x 1-5/7-inch cap screws "A" (Illust. 19) and three 3/8 N. C. x 1-3/8-inch cap screws "B" and remove the belt pulley and housing, complete. Set the belt pulley and cap screws aside for future use.



Illust. 19
Belt pulley and power take-off.

Replace the removed cap screws with the extra cap screws supplied with the belt pulley and power take-off. Use two 3/8 N. C. x 1-3/8-inch cap screws at "A" (Illust. 19A) and the three 3/8 N. C. x 1-1/8-inch cap screws at "B". Use flat washers in front of the lock washers and tighten the cap screws securely.



Safety First! Always cover the power take-off exposed shaft with the guard "C" (Illust. 19A) when the power take-off is not being used.


The specifications for the power take-off will be found on

CHANGING FROM POWER TAKE-OFF TO BELT PULLEY

Remove two 3/8 N. C. x 1-3/8-inch cap screws "A" (Illust. 19A) and the three 3/8 N. C. x 1-1/8-inch cap screws at "B". Apply a light coating of grease to the power take-off shaft and female spline in the belt pulley housing. Then slide the belt pulley and housing complete on to the power take-off splined shaft.

Insert the two 3/8 N. C. x 1-5/8-inch cap screws with lock washers at "A" (Illust. 19) and the three 3/8 N. C. x 1-3/8-inch cap screws with lock washers at "B" and tighten all cap screws securely.

Check the lubricant in the belt pulley housing as instructed in "Lubrication Guide" on page 65.



Illust. 19A
Power take-off.

COOLING SYSTEM

The thermo-siphon principle for circulating water in the cooling system. (The temperature of the water governs the rate of circulation.) Therefore, a thermostat and a water pump are not required.

When the tractor is shipped from the factory it is equipped with a nonpressure-type radiator cap.

A pressure-type radiator cap is available from your International Harvester dealer as a replacement for the regular production radiator cap, if so desired.



Caution must be exercised in removing the pressure-type radiator cap when the water in the cooling system is hot. See instructions in the following section.

When the radiator is equipped with a non-pressure-type radiator cap, the water is circulated through the engine block, cylinder head, and radiator by the thermosiphon method. As the engine warms up, the water is heated, expands, and circulates back through the radiator where the water is cooled before again circulating through the engine.

When the radiator is equipped with a pressure-type radiator cap, the cooling system operates under pressure which is controlled by means of a regulating valve built into the radiator cap. Always use clean water (soft or rain water if possible).

FILLING THE COOLING SYSTEM

Be sure the radiator drain plug (Illustr. 21) is closed; then fill the radiator to a level slightly below the bottom of the filler neck, when equipped with a nonpressure-type radiator cap; or to a level approximately 2-inches below the top of the filler neck, when equipped with a pressure-type radiator cap. Filling the radiator to this level will allow for expansion of the coolant under normal operating conditions. Use clean water; soft or rain water is recommended, as it does not contain alkali, which forms scale and eventually clogs passages.

Before replacing the filler cap, be sure to remove any chaff or dirt particles which may be on the gasket surface or cap, and tighten the cap clockwise to the stop.

Note: A pressure-cooled system will not operate properly unless the cooling system is tight.

The gasket surface must be in good condition. The cap must be properly tightened to the stop, and the system must not have loose connections or leaks. Unless these instructions are followed, pressure will not be maintained, and loss of water and consequent overheating will result. When draining the radiator, always remove the filler cap to permit complete drainage.

If the valve is faulty, replace it with a new radiator cap of the same type.

Do not attempt to repair or replace any of the regulating valve parts.


If the engine is to be operated in freezing temperatures, refer to "Cold Weather Precautions."

ADDING WATER TO THE COOLING SYSTEM (When Equipped with Pressure-Type Radiator Cap)



Caution! If the water in the cooling system is hot and water is to be added, observe the following:

Turn radiator cap "A" (Illustr. 20) slowly counterclockwise to the safety stop to allow the pressure of any steam to escape; then press down on the cap and continue to turn until the cap is free to be removed.



- "A" Radiator cap. "D" Upper water tank.
"B" Filler cap gasket. "E" Overflow pipe.
"C" Filler neck.

Illustr. 20

Water level in pressure-cooled radiator.

COOLING SYSTEM

ADDING WATER TO THE COOLING SYSTEM (When Equipped with Pressure-Type Radiator Cap) - Continued

Allow the engine to cool and fill the radiator slowly to approximately 2-inches below the top of filler neck "C". Due to expansion, when the system becomes hot, any excess water will be discharged through overflow pipe "E".

Note: Do not pour cold water into the radiator if the engine is very hot, unless conditions make it absolutely necessary; in which case start the engine, let it idle, and slowly pour water into the radiator.

CLEANING THE COOLING SYSTEM

Twice a year or more often, depending upon the mineral content of the water used, the cooling system should be drained and thoroughly flushed. This is particularly important before using an antifreeze solution.

If the engine is to be operated in freezing temperatures, refer to "Cold Weather Precautions" on page 50. For cooling system capacities, refer to page 66.

Drain the cooling system by removing the

plug on the bottom (center) of the radiator (Illustr. 21). Allow the system to drain; then replace the plug.

RUST PREVENTION

One of the most common causes of engine overheating is a rust-clogged cooling system. Rust interferes with circulation and cooling, which causes overheating.

The practice of flusing the system by forcing water from a hose in the radiator filler neck, without the use of cleaning solutions, may be only a waste of time. Iron corrosion is greater than that of any other cooling system metal, which accounts for the large quantities of rust found in neglected water jackets. Heavy rust deposits in the water jacket hold in heat and create local hot spots, especially around the exhaust valve seats. Under these conditions, the metal may get so hot that the valves will stick or burn, or the cylinder block or head may be damaged by heat cracking.


Unless the cooling water is treated with a corrosion preventive, rust and scale will eventually clog the passages in the radiator and water jacket. This condition is aggravated in some localities by the formation of insoluble salts from the water used.

IH Cooling System Cleaner, dissolves rust, scale, and sludge and retards future corrosion when used according to the directions on the container.

Note: Do not use chemical mixtures to stop radiator leaks except as a temporary measure in an emergency. Instead, have the radiator repaired.

If the radiator is clogged with insoluble salt formations, take it to a reputable concern specializing in the removal of such formations. Reliable radiator service stations are familiar with local conditions and are equipped to apply the proper treatment.

In localities where alkaline, acid, or saline waters are the only kind available, the addition of a rust preventive or "inhibitor" will tend to minimize the corrosive action of such water.



Illustr. 21
Cooling system.

COOLING SYSTEM

RUST PREVENTION - Continued

For rust prevention during winter use of the engine, a fresh filling of antifreeze containing an effective corrosion preventive should be used. In the spring, drain and discard the old antifreeze solution, as the rust preventive or "inhibitor" may be exhausted from contamination and continued use.


After draining the antifreeze, a rust preventive should be added to the cooling water to protect the cooling system during warm weather operation. This inhibitor solution should be drained and discarded in the fall when danger of freezing again makes necessary the use of an antifreeze.

RADIATOR CORE

Overheating is often caused by bent or clogged radiator fins. If the spaces between the radiator fins become clogged, clean them with forced air or water. When straightening bent fins, be careful not to injure the tubes or break the bond between the fins and tubes.

FAN BELT TENSION


Check the slack of the fan belt after every 50 hours of operation to assure maintenance of the correct tension. The tension is correct when the belt can be depressed without effort by the thumb, approximately $\frac{3}{4}$ -inch to 1-inch, midway between the two pulleys. See *Illust. 22*. If the slack is more than 1-inch, adjust the belt as follows:



Illust. 22
Correct belt tension.

Adjusting the Fan Belt

When the tractor is equipped with a generator, first loosen nuts "A" and "B" before



Illust. 22A
Fan and generator belts.

adjusting the fan belt tension. The tension of the fan belt is adjusted by loosening fan spindle "C" (*Illust. 22A*) and moving the fan and hub assembly up or down until the correct tension is obtained. After the correct tension is obtained, tighten fan spindle "C". To adjust the generator belt, see "Generator Belt."

After a new belt has been in use approximately 50 hours, check the tension and adjust again if necessary.

Removing the Fan Belt

To remove the fan belt, loosen fan spindle "C" (*Illust. 22A*) and slide the fan and hub assembly to the bottom of the groove on the crank-case front cover. The fan belt can then be slipped over the bottom drive pulley and worked up over the fan blades.

Replacing the Fan Belt

Replace the fan belt when it becomes soaked with grease, or when it is so badly worn that it does not drive the fan at the proper speed.

When replacing the belt, reverse the procedure outlined under "Removing Fan Belt," except that belt can be started on the lower pulley by hand, and by slowly cranking the engine, the belt will find the correct position.


COOLING SYSTEM

GENERATOR BELT

After the fan belt tension has been adjusted, move the generator toward or away from the engine to get the correct generator belt tension; then tighten nuts "A" and "B." The generator belt should be tight enough as not to allow slippage, but not so tight as to cause side thrust on the generator bearing. Allow 1/4-inch slack. See Illust. 22.

FAN HUB LUBRICATION

Every six months or after every 500 hours of operation, whichever occurs first, remove oil retainer screw "F" (Illust. 22A) and turn the fan assembly so that the oil filler hole is at the right horizontal position. Add engine oil until the oil reaches the level of the hole. Now turn the assembly so that the hole is on the bottom and allow any excess oil to drain out. The oil is then up to level of the top of the stand pipe (approximately 1-1/2 ounces). See Illust. 23. Replace the oil retainer screw and



Illust. 23

Fan hub partially disassembled showing oil level.

be sure that the retainer screw gasket is in place.

Note: The rubber gasket located behind the hub at "E" (Illust. 22A) is used for shipping purposes only. It does not have to be replaced when worn out.


AIR CLEANING SYSTEM

Clean air for combustion is assured by an oil-type air cleaner. A heavy screen in the air intake cap prevents large particles from entering the air cleaner. The air then passes to the oil cup where it goes through a bath of oil. As the air rises to the intake manifold, it passes through a series of oil-bathed screens and the fine dust is removed. As the oil from the screen works back down, it carries the dirt with it and settles in the oil cup. Never allow dirt to build up in the cup more than 1/2-inch deep.

OIL CUP SERVICE

Clean and refill the oil cup every day, or every 10 hours of operation (more frequently when operating under dusty conditions). Refill the oil cup to the oil level bead with the same grade of oil used in the engine crankcase. For the oil cup capacity, refer to page 60.

Do not remove the oil cup while the engine is operating. Before replacing the oil cup, clean or wipe oil or grit from the top bead of the oil cup.




Illust. 23A

Servicing the oil cup.

AIR CLEANING SYSTEM

AIR INTAKE CAP AND SCREEN

The screen in the air intake cap prevents chaff and other coarse dirt from getting into the air cleaner. Keep this screen clean and free from all chaff, oil, dust, or paint, as clogged holes in the screen will reduce the power of the engine by restricting the flow of air.



Illust. 24
Exploded view of air cleaner.

WASHING THE CLEANER

After every 150 hours of operation — particularly if operating the tractor in an atmosphere heavily laden with dust, chaff or lint — remove the entire air cleaner from the tractor, disassemble it (Illust. 24) and wash the parts thoroughly in kerosene. Be sure to clean out the air intake pipe.

After all parts have been thoroughly cleaned, replace the air cleaner body on the tractor. Make sure all joints are airtight. Replace the air intake cap. Fill the oil cup to the proper level with the specified grade of oil and replace it on the air cleaner. Be sure it is held securely in place by the oil cup bail or clamp.

GENERAL PRECAUTIONS

As an added precaution against dirt entering the engine, frequently inspect the flexible rubber hose connections between the carburetor and the air cleaner. If they show any sign of deterioration, replace them. To eliminate strain on the rubber hose connections, be sure the pipes line up. All joints between the air cleaner, carburetor, manifold and cylinders of the engine should be tight. All gaskets must be in good condition and the bolts should be drawn up tight.

CRANKCASE BREATHER


The crankcase breather and oil filler cap (Illust. 7) has an oiled aluminum crimp filler which acts as a dust filter for crankcase ventilation. Clean and reoil this breather each time the engine oil is changed.

ELECTRICAL SYSTEM

The six-volt electrical system of the tractor consists of a generator, voltage regulator, cranking motor, lights, lighting switch, electrical instruments, a six-volt battery, and either a magneto or a battery ignition unit. Colored plastic-covered cables are contained in a harness of nonmetallic, oilproof, and waterproof woven braid.

Use the illustrations on pages 24 and 25, and the wiring diagrams on pages 34 to 36 as a guide for identifying the various electrical units and for tracing the electrical cables and connections. Be sure all terminals are clean and securely fastened.

When the electrical equipment was installed at the factory, the battery-to-ground cable was left disconnected and taped. Before attempting to start the tractor, make certain that the ground cable is connected.



Illust. 24A
Battery and cables.


ELECTRICAL SYSTEM

SPARK PLUGS AND CABLES

Note: Remove all dirt from the base of the spark plug before removing the spark plug.

Remove the spark plugs after every 200 to 300 hours of operation for cleaning and checking the gaps between electrodes. A gap of .023 inch should be maintained.

When making this adjustment, always bend the outer electrode. Never bend the center electrode, as it will damage the insulator. If the gap between the electrodes is too great, due to improper setting or burning off of the ends, the engine will misfire and be hard to start.



Illust. 25A
Checking the spark plug gap.

Cleaning the Spark Plugs

Sandblasting is the recommended method of cleaning spark plugs. Never scrape or clean the insulator with anything which will scratch the porcelain. Scratched porcelain allows carbon and dirt to accumulate much faster.

Always use a spark plug wrench when removing or replacing plugs. This helps to prevent cracking the porcelain.

Screw the spark plugs into the cylinder head, using a new copper gasket with each one. Do not tighten more than enough to compress the gasket to seal the plug and assure a good heat transfer between the plug and the cylinder head. Torque the spark plugs to 34 foot-pounds torque. If a torque wrench is not available, tighten the plug 1/2 to 3/4 turns past finger tight.


Replace defective plugs with new plugs.

See your International Harvester dealer for various makes of replacement plugs for normal or special service. These plugs have been tested and recommended as best suited for this engine.

If the spark plug cables are removed for any reason, note the position of each cable on the distributor cap as shown in **Illust. 26**.

ELECTRICAL SYSTEM

SPARK PLUGS AND CABLES - Continued



Illust. 26


Spark plug wiring. Engine firing order is 1, 3, 4, 2.
(Magneto shown on the engine.)

MAGNETO

Greasing the Breaker Mechanism and Checking the Points

It is important that the breaker chamber be kept clean, as oil on the breaker points will cause rapid burning. Inspect the breaker chamber after every 250 hours of operation, to assure that it is clean. To reach the breaker mechanism, remove the distributor cap, and crank the engine slowly until end "B" of the distributor rotor arm points toward the No. 1 terminal on the distributor cap, and the impulse coupling just trips. Take off the distributor body by removing three screws "A" (Illust. 27). See that the points are in good condition and have the proper clearance. If the chamber is clean, no attention is necessary other than checking the clearance of the points, but if the chamber is dirty, all parts must be thoroughly cleaned.

Do not crank the engine while distributor body is removed or it might be necessary to retune the magneto to the engine.



Illust. 26A
Adjusting the breaker points.

Remove the breaker arm from the chamber and clean all parts. Inspect the breaker points and, if necessary, dress them with a sharp, fine file. If the points are worn excessively, replace both points.

Fill the recess in the breaker post with IH High Temperature Grease (21372-D) and pack a small quantity of the same grease in back of the breaker arm rubbing block (Illusts. 26A and 27). See your International Harvester dealer for the proper grease to use.


Replace the breaker arm and be sure the points line up when the breaker arm is in place.

Check the opening between the breaker points (Illust. 26A) with a feeler gauge. The point opening should be .013 inch when the rubbing block is on the high part of the cam. If the opening is not correct, adjust it by loosening the screw holding the adjustable point (Illust. 26A) and moving the point up or down until the gauge slips snugly into the opening. After the proper adjustment has been made, tighten the screw.

With the engine on the top dead center of the No. 1 firing stroke, turn the distributor rotor until end "B" of the distributor rotor arm points to the No. 1 terminal on the distributor cap. Place the distributor body on the magneto and be sure the rotor shaft enters the "D" shaped hole in the magneto rotor pinion. Be sure the gasket is in place and tighten three screws "A" (Illust. 27). Replace the distributor cap.

ELECTRICAL SYSTEM

MAGNETO - Continued



Illust. 27
Magneto disassembled.

Greasing the Distributor Gear

After every 2,000 hours of operation or at least every year, the distributor gear and distributor gear chamber should be cleaned and repacked with IH Magneto Ball Bearing Grease (359 766 R91). We recommend this be done by your International Harvester dealer.

Distributor Cap

Every three or four months, remove the distributor cap and examine the inside. If any dust, moisture or oil deposits are present, thoroughly clean and wipe dry. To assure long life of the distributor, care must also be taken to keep the three small ventilator holes in the bottom of the distributor cap open at all times. Also see that the distributor rotor is kept clean.

If the distributor cap terminal nipples are removed, be sure that the terminals and coil cover terminals are clean and dry.

The magneto is equipped with these nipples to prevent any external electrical leakage when the tractor is operating under adverse conditions.

Magneto Impulse Coupling and Magneto Drive Chamber

When the engine is hand-cranked, the impulse coupling should trip (click) twice for each revolution of the engine. Failure to do so indicates the need of cleaning or service.

Remove the magneto as described below. Hold the magneto at an angle of approximately 45 degrees, and flush the impulse coupling and magneto drive chamber with kerosene. During warm weather, oil the impulse coupling liberally with light oil, such as cream separator or sewing machine oil. Do not use oil during cold weather (below +10 degrees F.). Flushing with kerosene is all that is required.

If it is necessary to remove the impulse coupling from the magneto for cleaning or service, we recommend that this be done by your International Harvester dealer.


Removing the Magneto

1. Disconnect switch cable "A" (Illust. 28) by removing the nut and lock washer attaching the cable to the magneto terminal.

ELECTRICAL SYSTEM

MAGNETO - Continued

Removing the Magneto - Continued



Illust. 28
Removing the magneto.

2. Pull out cable "B" from coil cover "C" and remove the distributor cap.


3. Loosen the nut holding magneto mounting clip "D" and remove cap screw "E". The magneto assembly can then be removed. See Illust. 28.

Installing and Timing the Magneto to the Engine

1. Crank the engine until the No. 1 piston (the piston next to the radiator) is on the top dead center of the compression stroke. The compression stroke can be determined by removing the No. 1 spark plug, placing the thumb over the opening, and cranking the engine until an outward pressure is felt. Continue cranking slowly until the top dead center mark (second notch on the back flange of the fan drive pulley at the left side of the engine) is in line with pointer on crankcase front cover. See Illust. 28B. Both intake and exhaust valves will now be closed.

2. Turn the magneto impulse coupling (Illust. 29), in a counterclockwise direction (as viewed from the coupling end) until end "B" of the distributor rotor arm points toward the No. 1 terminal on the distributor cap. See Illust. 27. Then replace the distributor cap.


3. Assemble the magneto on the engine, making sure that the lugs on the impulse coupling engage in the slots on the magneto drive



Illust. 28A
Magneto wiring (clockwise rotation).
Firing order 1, 3, 4, 2.

coupling. (Assemble the magneto so that the top is as close to the crankcase as possible.)

4. Insert magneto mounting bolt "E" loosely in the magneto flange, just enough to hold the magneto in place. Then crank the engine one complete revolution to the next top dead center. Now pull the upper part of the magneto away from the engine until the impulse coupling just trips.




Illust. 28B
Notches on the fan drive pulley and the timing pointer.

ELECTRICAL SYSTEM

MAGNETO - Continued

Installing and Timing the Magneto to the Engine - Continued



Illust. 29

Magneto removed showing impulse coupling.

5. Tighten mounting clip nut "D" and bolt "E" (Illust. 28) securely. If the spark plug cables have been removed for any reason, attach the cables to the engine and magneto. Start by connecting the No. 1 cylinder spark plug to the socket marked "1" on the distributor cap in Illust. 26. Then connect the No. 3 socket with the No. 3 cylinder; next the No. 4 socket with the No. 4 cylinder, and last, the No. 2 socket with the No. 2 cylinder. See Illusts. 26 and 28A.

6. Connect the switch cable to the magneto terminal. See "A", Illust. 28.


7. To check the timing, crank the engine slowly until the top dead center of the No. 1 cylinder is reached; at this time the impulse coupling should just trip. Never time before top dead center.

8. The magneto is now correctly wired and timed.

9. Push cable "B" back into the socket in the coil cover. See Illust. 28A.

DISTRIBUTOR AND COIL UNIT

Greasing the Breaker Mechanism and Checking the Points



Illust. 29A

Adjusting the breaker points.

It is important that the breaker chamber be kept clean because oil on the breaker points will cause rapid burning. Remove the distributor cap, distributor rotor, and the breaker cover for breaker chamber inspection. See Illust. 29A. Care should be taken, when removing the breaker cover, to keep dirt from entering the breaker chamber. Be sure the chamber is clean and that the breaker points are in good condition and have the proper opening.


Never use emery cloth or sandpaper to clean the points. To dress the points, use a sharp fine file. If the points are worn excessively, replace both points.

Fill the recess in the breaker post with IH High Temperature Grease (21372-D) and pack a small quantity of the same grease in back of the breaker arm rubbing block and apply a light coating of the same grease on the lobes and flats of the breaker cam. See Illusts. 29A and 30. See your International Harvester dealer.

ELECTRICAL SYSTEM

DISTRIBUTOR AND COIL UNIT - Continued

Greasing the Breaker Mechanism and Checking the Points - Continued



Illust. 30

Distributor partially disassembled for servicing.


Check the condition of the breaker points for build-up or lip formation. If present, the points must be dressed before the point opening can be checked or set. Check the opening between the breaker points with a feeler gauge as shown in Illust. 29A. The point opening should be .020 inch when the rubbing block is on the high part of the cam. If the opening is not correct, adjust it by loosening the screw holding the adjustable point. Then move the point toward or away from the point on the breaker arm until the gauge slips snugly into the opening. After the adjustment has been made, tighten the screw.

If the spark plug cables have been removed for any reason, attach the cables to the spark plugs and to the terminal sockets of the distributor cap in the following order: The No. 1 cylinder spark plug cable to the socket marked "1" in Illust. 30A. Then, going around the distributor cap in a clockwise direction, attach the cable from the No. 3 spark plug to the next or second socket, the cable from the No. 4 spark plug to the next or third socket, and the cable from the No. 2 spark plug to the fourth or last socket. Assemble the secondary cable "A" in the distributor cap. See Illust. 30A.

Distributor Cap

Every three or four months, remove the distributor cap and examine the inside. If any dust, moisture, or oil deposits are present, thoroughly clean and wipe dry. Also see that the distributor rotor is kept clean.

If the terminal nipples are removed, be sure the distributor cap terminals and coil terminal are clean and dry. The distributor is equipped with these nipples to prevent any external electrical leakage when the tractor is operating under adverse conditions.




Illust. 30A

Distributor wiring and lubrication.

ELECTRICAL SYSTEM

POWER TIMING LIGHT



Illustr. 31

Notches on the fan drive pulley and the timing pointer.

A final check and adjustment of the ignition should be made with a neon-type flashing timing light synchronized to the ignition system and directed at the timing mark on the rear flange of the crankcase fan drive pulley. See your International Harvester dealer for this service.

IGNITION COIL

The ignition coil does not require special service other than to keep all terminals and connections clean and tight.


GENERATOR AND REGULATOR

The generator supplies current to keep the battery in a charged condition, replacing the energy consumed by the cranking motor and lights. It is hinge-mounted on the right side of the engine crankcase and is driven by a V-belt from the fan pulley.

The generator charging rate is controlled by a voltage regulator which controls the generator output, thereby maintaining a satisfactory charging rate, and prevents overcharging the battery under varying temperatures and operating conditions. It should not require

adjustment or attention. If the regulator fails to operate correctly, see your International Harvester dealer.

POLARIZING THE GENERATOR



Illustr. 31A

Polarizing the generator.

If the generator or the regulator has been removed or the leads disconnected, the generator should be repolarized. After the leads have been reconnected, but before the engine is started, proceed as follows:

After making certain that the grounded battery terminal is the positive (+) terminal, momentarily connect a jumper lead between the "BAT" and the "GEN" terminals of the regulator. See Illustr. 31A. This allows a momentary surge of current to flow through the generator which correctly polarizes it. Reversed polarity may result in vibration, arcing, and burning of the relay contact points.

GENERATOR BELT TENSION

The tractors have separate fan and generator belts. To check, adjust, or replace the belts, refer to pages 22 and 23.

HEADLIGHTS


The headlights are sealed-beam lights especially developed for tractor operations. The parts are so constructed that the filament, reflector, and lens are all assembled in a unit permanently sealed against dirt, moisture, and corrosion. If a filament burns out or a lens breaks, the complete unit must be replaced. See your International Harvester dealer.

ELECTRICAL SYSTEM

COMBINATION REAR LIGHT AND TAILLIGHT

The combination rear light and taillight is turned on by the lighting switch on the instrument panel and gives you a choice of red as a taillight for highway use or white as a rear light for field use. Should a lens break, or a filament burn out, the complete sealed beam unit must be replaced. See your International Harvester dealer. To replace the taillight lamp, remove the sealed beam unit and replace the taillight lamp with a 15 candle power lamp (6-volt, No. 454 493).

TAILLIGHT



Illust 32
Taillight.

To replace the taillight lamp remove the red lens from the taillight and replace defective lamp with a new 3 candle power lamp (No. 142 303).

FUSE

A cartridge-type SFE-20 ampere fuse is located in the fuse housing. If a short circuit occurs in the lighting circuit, the fuse will burn out and break the circuit, preventing damage to the electrical system.

It is important to use the same capacity fuse for replacement. If the lights fail, check the fuse. If the fuse continually burns out, check the electrical wiring for short circuits.

To install a new fuse, unscrew the fuse holder on the instrument panel, pull out the old fuse and replace it with a new one.

STORAGE BATTERY

Cleaning and Servicing the Battery

Occasionally remove the battery cable and ground strap, brighten the terminal contact surface with wire wool, and reassemble. Then apply a light coat of vaseline or chassis lubricant. Be sure the terminals are clamped tightly and that the battery is fastened securely to the battery support. Replace damaged cables. Keep the vent holes in the battery filler caps open.

Liquid Level

Check the battery at least once a month for water level. If the battery is in need of charging, it should be given immediate attention. Keeping the battery fully charged not only adds to its life but makes it available for instant use when needed.

The electrolyte (acid and water) in each cell should be at the proper level at all times to prevent battery failure. When the electrolyte is below this level, pure, distilled water should be added.

Acid or electrolyte should never be added except by a skilled battery man. Under no circumstances add any special battery "dopes", solutions, or powders.



Caution! Electric storage batteries give off highly inflammable hydrogen gas when charging and continue to do so for some time after receiving a steady charge.



Do not under any circumstances allow an electric spark or an open flame near the battery. Do not lay tools across battery terminals as this may result in a spark or short circuit which may cause an explosion. Be careful to avoid spilling any electrolyte on hands or clothing.

For dependable battery service see your International Harvester dealer.

Specific Gravity


The specific gravity of the electrolyte indicates the relative condition of the battery charge and warns when it may be necessary to recharge the battery.

Continued on next page.

ELECTRICAL SYSTEM

STORAGE BATTERY - Continued

Specific Gravity - Continued



Illust. 33

Taking a hydrometer reading of electrolyte in the battery.

Inspect the battery once every two weeks to maintain the correct specific gravity. The specific gravity of a fully charged battery is 1.255 to 1.270 corrected to +80°F. (liquid temperature). A specific gravity reading of at least 1.230 corrected to +80°F. should be maintained. Never allow the battery to fall below 1.230.

The specific gravity reading will vary with the temperature of the electrolyte. For readings taken at any temperature other than +80°F., a temperature correction must be applied. This is done by adding .004 specific gravity for every 10° above +80°F., and by subtracting .004 specific gravity for every 10° below +80°F.

Example No. 1

Hydrometer reading 1.270
Electrolyte temperature +20°F.
Subtract .024 Sp. Gr. (.004x6)
Corrected Sp. Gr. is 1.246

Example No. 2

Hydrometer reading 1.255
Electrolyte temperature +100°F.
Add .008 Sp. Gr. (.004x2)
Corrected Sp. Gr. is 1.263

Use an accurate hydrometer when testing for specific gravity. Readings should not be taken immediately after adding water. All cells should show approximately the same specific gravity reading. Wide variations indicate something is wrong.

Cold Weather Operation

It is especially important to keep the battery close to full charge for cold weather operation. Add water to the battery in freezing temperatures only when the tractor is to operate for several hours, to thoroughly mix the water and electrolyte, or damage to the battery will result from the water freezing.

The electrolyte of a battery in various stages of charge will start to freeze at temperatures indicated below:

Specific Gravity (Corrected to +80°F.)	Freezing Temperature Degrees Fahrenheit
1.265	-80°F.
1.220	-30°F.
1.210	-20°F.
1.180	-10°F.
1.160	0°F.
1.140	+10°F.
1.100	+20°F.
1.000	+30°F.

The temperatures shown indicate the approximate points at which the first ice crystals begin to appear in the solution. The solution does not freeze solid until a lower temperature is reached.

A battery three-fourths charged is in no danger of damage from freezing. Therefore keep the battery better than three-fourths charged, especially during winter weather.


If your tractor is not to be operated for some time during the winter months, it is advisable to remove the battery and store it in a cool, dry place above freezing (+32°F.). Place the battery on a rack or bench.

Ground Strap

When replacing a battery, make certain that the ground strap is connected to the positive (+) terminal on the battery.

Note: Before working on any part of the electrical system, disconnect the battery ground cable from the battery terminal. Do not reconnect it until all electrical work has been completed. This will prevent shorting and causing damage to any of the electrical units.

ELECTRICAL SYSTEM








Illust. 34

Electric starting and lighting wiring diagram for tractors equipped with magneto ignitions.

Ref. No.	Description	Ref. No.	Description
1	Cable - battery to starting switch	19	Headlights
2	Cable harness - rear light	20	Magneto ignition switch
3	Cable - taillight to junction block	21	Cable - regulator "BAT" terminal to charge indicator - gray
4	Taillight	22	Cable - regulator "L" terminal to junction block cable - light green
5	Battery	23	Cable - starting switch to charge indicator - brown
6	Cable - battery to ground. Ground on bolt through battery box side	24	Cable - orange - taped at both ends
7	Cable harness	25	Cables - lighting switch to headlights - black
8	Cable - generator "F" terminal to regulator "F" terminal cable	26	Cable - headlight to ground - pink
9	Cable - generator "A" terminal to regulator "GEN" terminal	27	Cable - "RL" terminal to rear light taped at rear light - red
10	Cranking motor	28	Cable - fuse housing to lighting switch
11	Magneto	29	Cable - fuse housing to junction block
12	Voltage regulator	30	Cable - junction block to ground - pink
13	Generator	31	Cable - lighting switch to junction block - black
14	Charge indicator	32	Cable - dark green taped at both ends
15	Lighting switch		
16	Fuse housing		
17	Junction block		
18	Cable magneto ignition switch to magneto		

ELECTRICAL SYSTEM




B-12887

Illust. 35
Electric lighting wiring diagram for
tractors equipped with battery ignition.

Ref. No.	Description	Ref. No.	Description
1	Cable harness - rear light	10	Fuse housing
2	Cable - "RL" terminal to rear light taped at rear light - red	11	Cable - fuse housing to lighting switch "BAT" terminal - long
3	Cable - junction block to ground bolt - pink	12	Cable - fuse housing to "IGN" switch terminal - short
4	Junction block	13	Headlight
5	Taillight	14	Line connector
6	Cable - taillight to junction block	15	Cables - harness to headlight cable assembly
7	Cable - junction block to lighting switch "TL" terminal - black	16	Headlight cable assembly
8	Lighting switch		
9	Cables - lighting switch "HL" terminal to headlight connectors		

ELECTRICAL SYSTEM



B-12888

Illust. 36
Electric starting wiring diagram for
tractors equipped with battery ignition.

Ref. No.	Description	Ref. No.	Description
1	Cable - battery to starting switch	12	Battery ignition switch
2	Battery	13	Cable - regulator "BAT" terminal to charge indicator positive terminal - gray
3	Cable - battery to ground	14	Cable - regulator "L" terminal to battery ignition switch cable - light green
4	Cable harness	15	Cable - starting switch to charge indicator negative terminal - brown
5	Cable - generator "F" terminal to regulator "F" terminal	16	Cable - ignition switch to coil negative terminal - orange
6	Cable - generator "A" terminal to regulator "GEN" terminal	17	Cables - taped
7	Generator	18	Cable - headlight to ground - pink
8	Voltage regulator	19	Cable line connector to horn - taped - dark green
9	Battery ignition unit		
10	Cranking motor		
11	Charge indicator		

MINOR ENGINE SERVICE OPERATIONS

CYLINDER HEAD GASKET

Check the tightness of the cylinder head bolts after the first 50 hours of engine operation for a new tractor and 50 hours after installing a new cylinder head gasket. The bolts should be tightened to, from 80 to 90 foot-pounds torque.

For most satisfactory results in tightening the cylinder head after installing the cylinder head gasket, tighten down all the cylinder head bolts fairly snug, starting with the row in the center, then going to the others. Retighten in the same order, giving each bolt a fraction of a turn at a time. Continue this until all bolts are tight. Do not screw one bolt down perfectly tight and then go on to the next as you will not obtain an even pressure on the gasket in this manner.

After replacing the cylinder head, it is necessary to insure against leaks by retightening the bolts after the engine has been operating and the water jacket has become thoroughly heated.

Note: Be sure to adjust the valve tappet clearance after the last tightening of the cylinder head bolts. See "Valve Clearance Adjustment".

CRANKSHAFT BEARINGS, PISTONS, AND RINGS

We cannot impress too strongly the necessity of having your International Harvester dealer do the work of replacing the connecting-rod bearings, crankshaft bearings, pistons and rings, and reconditioning the valves.

VALVE CLEARANCE ADJUSTMENT

Check the valve clearance after every 500 hours of operation and adjust the clearance if necessary. A clearance of .013 inch, measured when the valves are closed and the engine is cold, is necessary between the end of the tappet adjusting screw and the valve stems.

When engine valves are equipped with positive-action valve rotators, check the valve clearance after 50 hours of operation, and after every 150 hours thereafter until the clearance remains the same between two checks.

The loss of valve lash is due to the valve seating without the accompanying build-up of deposits as experienced with standard (non-rotating) valves.

Adjusting the Clearance

1. To safeguard against accidentally starting the engine when checking the valve clearance, remove cable "B" from the coil cover on the magneto (Illust. 29) or remove distributor-to-coil cable "A" from the socket on the coil of the battery ignition unit. See Illust. 30A.


2. Remove the valve cover from the left side of the crankcase.

3. Remove the spark plug from the No. 1 cylinder (the cylinder next to the radiator).

4. Place your thumb over the spark plug opening and slowly crank the engine until an outward pressure is felt. (Pressure indicates that the No. 1 piston is moving toward the top dead center of the compression stroke.) Continue cranking slowly until the top dead center mark (second notch on the back flange of the fan drive pulley at the left side of the engine) is in line with the timing pointer in the front crankcase cover. See Illust. 31. Both valves are now closed on the compression stroke of the No. 1 cylinder.

5. Use two thin wrenches when adjusting the valve clearance. See Illust. 37. Use the lower wrench to hold the tappet and the upper wrench to raise or lower the tappet adjusting screw. A gauge of .013-inch thickness should slip snugly between the valve stem and the tappet adjusting screw.

6. Crank the engine one-half revolution at a time and check the clearance of each cylinder's valves and adjust if necessary. Do this on each set of cylinder valves in succession according to the firing order of the engine, which is 1, 3, 4, 2.



Illust. 37

Adjusting and checking valve clearance.

MINOR ENGINE SERVICE OPERATIONS


VALVE CLEARANCE ADJUSTMENT - Continued

Adjusting the Clearance - Continued

7. Replace the valve cover. Check to see that the valve cover gasket makes an oiltight seal with the crankcase. Replace the gasket if necessary.

8. Replace magneto cable "B" (Illust. 29) or distributor-to-coil cable "A" (Illust. 30A) into the socket from which it was removed.

Note: Be accurate — use a feeler gauge for checking the valve clearance.



Illust. 38

Battery ignition unit and tachometer drive.

TACHOMETER DRIVE UNIT


If for any reason the drive gear housing must be removed, proceed as follows:

Remove the two screws and the tachometer drive housing retainer plate. Then remove the housing and drive gear assembly.

If the drive gear housing is disassembled for any reason, inspect the drive gear and replace it with a new one, if necessary. Before reassembly, apply IH Magneto Ball Bearing Grease (359 766 R91) or chassis lubricant to the space and bearing surfaces shown in Illust. 38A.

Assemble the tachometer drive gear and housing, complete with the gasket, into the distributor drive housing (Illust. 38). Assemble the retainer plate, screws, and lock washers and tighten them securely.


To prevent failures of the tachometer drive shaft and tachometer drive gear, it is important for the drive shaft to follow a smooth even path from the distributor drive housing to the tachometer. No bend in the shaft should be sharper than a 5-inch radius.



Illust. 38A

Tachometer drive installation diagram.

FRONT WHEELS



Illust. 39
Front wheel with disc flange turned in.


The front wheels are steel disc wheels with attached rims for 4.00-12 and 4.00-15, 4-ply tractor-type tires.

The wheels are provided with mounting holes for the addition of cast iron wheel weights.

Each wheel is mounted on the hub with five special bolts and may be mounted with the disc flange turned in or out to obtain different treads.

The hubs rotate on tapered roller bearings. An oil seal and felt washer are used at the inner end of the hubs.

The front wheels can be adjusted to treads of 40-5/8-inches or 46-3/8-inches. The wheels are in the 40-5/8-inch tread position when the disc flanges are turned in. See Illust. 39. To obtain the 46-3/8-inch tread, reverse the wheels on the hubs so that the disc flanges are turned out. See Illust. 39A.



Illust. 39A
Front wheel with disc flange turned out.

Note: The front wheels must not be mounted with the disc flanges turned out when the tractor is carrying heavy front end weight.

Check the hub bolts for tightness every month or after every 250 hours of operation. Keep them tightened to from 56 to 63 foot-pounds torque.

ADJUSTABLE WIDE-TREAD FRONT AXLE

Tractors equipped with an adjustable front axle: The front wheels can be set at treads of 40-5/8, 44-5/8, 48-5/8, 52-5/8 and 56-5/8-inches to track with respective rear wheel tread positions.

Note: The front wheels must not be mounted with the disc flanges turned out when the tractor is carrying heavy front end weight.

Check the hub bolts every month or after every 250 hours of operation to make sure that they are kept tightened at 56 minimum to 63 maximum foot-pounds torque.

FRONT WHEELS

ADJUSTABLE WIDE-TREAD FRONT AXLE - Continued

Adjusting the Tread Widths


1. Raise the front end of the tractor.
2. Loosen the bolts holding axle extension clamps "A".
3. Pull the cotter pins and remove axle extension clamp pins "B". Remove the bolts from tie rod clamps "C".
4. Pull the axle extensions out an equal distance on both sides to the desired tread position and move the tie rods to correspond.
5. Replace axle extension clamp pins "B" in the holes selected and tighten the clamps. Also replace and tighten the bolts in the tie rod clamps.

Adjusting the Toe-in

The front wheels should have $\frac{1}{4}$ inch ($\pm \frac{1}{16}$ -inch) toe-in ($\frac{1}{4}$ -inch closer in front than in the rear). To check the toe-in, place chalk marks at point "G" on each rim at hub height, *Illust. 40* and measure the distance between them. Move the tractor forward a distance equal to one-half revolution of the front wheels. The chalk marks should now be at point "F". The measurements between points "F" should be $\frac{1}{4}$ -inch ($\pm \frac{1}{16}$ -inch) greater than at "G".

To adjust the "toe-in", disconnect steering knuckle arms "E" at "D". Loosen the lock nuts and turn tie rod ends "D" in or out as required.

Be sure to make the arm adjustments equal.



Illust. 40
Adjustable front axle showing variable wheel treads.

REAR WHEELS

The rear wheels are steel disc wheels with demountable rims for tractor-type agricultural tread tires and are provided with mounting holes for the addition of cast-iron wheel weights.

The following rear wheel rims are available:

Rear wheel rim W5-30 for use with 7.2-30, 4-ply pneumatic tires.

Rear wheel rim W7-24 for use with 8.3-24, 4-ply and 9.5-24, 4-ply pneumatic tires.

The W5-30 and W7-24 rims are furnished with the tractor as ordered.

Each wheel is mounted on the axle flange with five special bolts and may be mounted with the disc flange turned in or out to obtain, with the different rim positions, the various

wheel treads described in the following paragraphs.


ADJUSTING THE TREAD WIDTHS

The rear wheels can be set in five different tread positions of 40, 44, 48, 52 or 56 inches to suit various crop spacings.


The desired tread position can be obtained by reversing the rear wheel discs and by attaching the rims to the discs in different positions as shown in Illusts. 41, 41A, and 42.

Note: When the rear wheel discs or rims are reversed, make sure that the tire tread will rotate in the correct direction as shown by the arrow on the side of the tires. See Illusts. 41 and 41A.

When assembling discs or rims, tighten all bolts securely. The rear wheel rim bolts and the rear wheel hub bolts should be kept tightened to from 85 to 95 foot pounds torque.




Illust. 41
Rear wheel with disc flange turned in.



Illust. 41A
Rear wheel with disc flange turned out.

REAR WHEELS



A-35893

Illust. 42
Rear wheel tread positions.


WEIGHTS

FRONT WHEEL WEIGHTS (One-Piece)


The one-piece front wheel weights weigh approximately 26 pounds each, and either one or two can be attached to the outside of each front wheel. To increase steerability, front wheel weights, are recommended for use as a front end counterbalance whenever heavy loads are superimposed on the drawbar, or when heavy equipment is to be mounted on the rear end of the tractor.

The first set of front wheel weights includes a set of two weights and four $1/2$ NC x $1-3/4$ -inch bolts, nuts and lock washers for attaching the weights to the front wheels at "A" (Illust. 43).

If additional weight is desired a second set of weights can be attached to the first weights by using four $1/2$ NC x $3-3/8$ -inch bolts, nuts and lock washers at "B" (Illust. 43A).




Illust. 43
First front wheel weight mounted on wheel.



Illust. 43A
First and second front wheel weights mounted on wheel.

FRONT WHEEL WEIGHTS (Two-Piece)



Illust. 43B
Two-piece front wheel weights.

WEIGHTS

FRONT WHEEL WEIGHTS (Two-Piece) - Continued

Two-piece front wheel weights are available to provide additional weight for the front end of the tractor when operating over hilly ground or when a scoop or scraper is being used on the rear of the tractor. These weights are mounted on the inside of each wheel. Each half weights approximately 25 pounds. A set of these weights can be used either with or without one or two one-piece weights attached on the outside of the wheel. See Illust. 43B.

When only a set of two-piece weights is to be attached, use eight 1/2NC x 3-1/4-inch bolts, nuts, and lock washers.

To mount a set of one-piece weights on the outside of the front wheels with two-piece weights on the inside, use eight 1/2NC x 4-1/4-inch bolts, nuts, and lock washers.

If additional weight is desired, a second set of one-piece weights can be added on the outside of the first set of one-piece weights, using eight 1/2NC x 5-3/4-inch bolts, nuts, and lock washers.

The rear wheel weights weigh approximately 150 pounds each and either one or two can be attached to each rear wheel to reduce slippage and tire wear and increase traction of rubber tired tractors.


The first set of rear wheel weights includes a set of two weights and eight 1/2NC x 3-inch bolts, nuts and lock washers for attaching the weights to the rear wheels at "A" (Illust. 44).

If additional weight is desired a second set of weights can be attached to the first weights by using four 1/2NC x 6-1/4-inch bolts, nuts and lock washers at "B" (Illust. 44A).

Before attaching the second rear wheel weights, it is necessary to remove two bolts from each first weight and replace them with the longer bolts provided with the second weights.

If the second weights are removed, the two shorter bolts in each first weight previously removed, must be reinstalled.

REAR WHEEL WEIGHTS



Illust. 44

First rear wheel weight mounted on wheel.



Illust. 44A

First and second rear wheel weights mounted on wheel.

PNEUMATIC TIRES

Observe the following instructions and recommendations in order to secure maximum life and efficient service from the pneumatic tires.

CARE OF TIRES

Avoid stumps; stones, deep ruts, and other hazards. Cuts in tires should be repaired immediately, as neglect decreases tire life. Keep the tires free from oil and grease, as both destroy rubber. After using the tractor for spraying (insect control work), use water to remove any chemicals that may be on the tires.

INFLATION

Keep the pneumatic tires properly inflated to the pressures shown in the tables. Underinflation will damage the tire cord body and may cause the tire to slip on the rim and tear out the tube valve stem. Overinflation results in excessive slippage, causing rapid tire wear.

Check the air pressure once a week with an accurate low-pressure gauge having one-pound graduations. Do not allow the air pressure to drop below the recommendations.

Always see that the tire valve caps are in place and are screwed tightly. The caps prevent the loss of air through the valve core, and keeps loose soil, mud, gravel, snow, and ice from entering and damaging the valve core.


Tires can be inflated with a pressure pump, hand pump, or a spark plug pump. Spark plug pumps can be purchased from International Harvester dealers.

USING THE SPARK PLUG TIRE PUMP

Note: Do not use a diesel engine as the source of power.

Remove one of the spark plugs from the tractor engine, or any carbureted engine, and replace it with pumping element "A" having the correct spark plug thread size. See **Illust. 45**. Attach one end "B" of the pump hose to the pumping element, and other end "C" to the valve stem of the tire to be inflated.

Start the engine and run it at low speed for maximum efficiency.



Illust. 45
Tire pump, hose, and air gauge.

SHIPPING TRACTORS EQUIPPED WITH PNEUMATIC TIRES

When tractors are transported on a carrier, such as a railroad car or trailer, rear tires should be inflated up to 30 pounds. Front tires to the maximum pressures shown in the table. The higher pressure must be reduced to operating pressure **BEFORE** the tractor is removed from the carrier. Inflation pressure should be as shown in the following tables to make possible rigid blocking and to prevent bouncing.

OPERATING PRESSURE FOR LOW-PRESSURE TRACTOR TIRES



Caution! Upon receiving your tractor, immediately adjust the air pressure in the tires as indicated in the tables.

Front Tire Loads in Pounds at Various Inflation Pressures
Underscoring indicates maximum recommended load.

Tire Size	Ply Rating	Pounds per square inch						
		20	24	28	32	36	40	44
		Kilograms per square centimeter						
		1.40	1.68	1.97	2.25	2.53	2.81	3.09
F-2 Tread								
4.00-12	4	330	365	400	435	465	495	<u>520</u>
4.00-15	4	390	435	475	515	550	585	<u>620</u>
I-1 Tread								
4.00-12	4	450	500	550	595	635	<u>675</u>	

PNEUMATIC TIRES

OPERATING PRESSURE FOR LOW-PRESSURE TRACTOR TIRES - Continued

Rear Tire Loads in Pounds at Various
Inflation Pressures
Underscoring indicates maximum recommended load.

Tire Size	Ply Rating	Pounds per square inch						
		12	14	16	18	20	22	24
		Kilograms per square centimeter						
		.84	.98	1.12	1.26	1.40	1.54	1.68
R-1 Tread								
8.3-24	4	965	1055	1140	1220	1300	1370	
9.5-24	4	1215	1330	1435	1535			
7.2-30	4	870	950	1030	1100	1170	1230	1300
R-3 Tread								
8.3-24	4	965	1055	1140	1220	1300	1370	
9.5-24	4	1215	1330	1435	1535			

Tire Code Marking	Tire Industry Type
F-2	Agricultural
I-1	Rib Implement
R-1	Agricultural
R-3	Industrial

When equipment is mounted on the tractor, the rear wheel tire loads may be increased up to 20 percent with no increase in inflation (as indicated in the tables and speeds do not exceed 10 miles per hour). Tire loads should be calculated to include FULL bins or tanks.

MOUNTING TIRES ON THE RIM

After mounting a new or old tire on the rim, inflate it to thirty pounds pressure to seat the tire bead on the rim flange and to keep the tire from creeping and shearing off the valve. Then deflate or inflate the tire to the correct operating pressure.

The brakes consist of external bands that contract on the brake drums. The brakes are controlled by foot pedals which can be operated individually or simultaneously when locked together.

Check the brakes for free movement and equal pressure after every 150 hours of operation until the proper interval is determined according to usage. Check the free movement thereafter as required to maintain equal pressure and efficient braking.

TRACTION AND WEIGHTS

The tractor should not be operated with the tires improperly inflated. To insure the maximum hours of service, watch the tread lugs; if they wear down too fast, immediately add more weight to cut down slippage. Check for high air pressure. Consult your International Harvester dealer for information.

WHEEL WEIGHTS

The drawbar pull of a tractor can be increased by adding cast iron weights to the driving wheels, and by the use of liquid in the tire tubes.

The amount of the increase in drawbar pull by the addition of certain definite weights varies with the type of soil. When very heavy weight is required, both liquid and cast iron weights can be used.

After adding weight to the rear wheels, it may be necessary to readjust the height of the drawbar to obtain the correct alignment.

OVERLOADING

Do not overload the tractor tires by mounting implements on the tractor which exceed the load capacity of the size of the tires on the tractor.

TIRE CHAINS

In wet grass or ground conditions, use lug-type chains. The flexing of the tire and the creeping of chains will break the mud loose as the wheel rotates. **Note:** There is a possibility of the tire slipping within the chain; to prevent this, the use of spring-type chain fasteners is recommended.

BRAKES


The brakes should not drag before they take hold. The pedals should have a free movement, by hand, of approximately 7/8-inch.

BRAKE ADJUSTMENT

To adjust the brakes, jack up the rear end of the tractor. Remove pin "A" and loosen lock nut "B". See *Illust. 47*. Turn adjusting yoke "C" until each wheel drags slightly when turned.

BRAKES

BRAKE ADJUSTMENT - Continued



Illust. 47
Brake pedal adjustment.

Replace pin "A" and tighten lock nut "B" after the adjustment has been completed.

It is very important to have the brakes equalized. To have equalized brakes, both pedals must have the same amount of free movement.

To check the equalization of the brakes, jack up both rear wheels so they will turn freely, block the tractor securely and latch the brake pedals together; then start the engine. Shift the gears to either third or fourth speed and engage the clutch; while the wheels are turning, apply the brakes.

Application of the brakes should slow down both wheels at the same time and also reduces the speed of the engine.

If one wheel stops and the other wheel continues to revolve when the brakes are applied, loosen the adjustment on the wheel that stops just enough so both wheels stop simultaneously when the brakes are applied.

CLUTCH

The engine is equipped with a spring-loaded, 6-1/2-inch diameter, single plate, dry disc clutch.

As a result of normal clutch facing wear, the free travel between the clutch release levers and the release bearing is reduced. Lack of clearance causes overheating of the clutch, loss of power, and early replacement of clutch facing.


Check the clutch for free movement after every 150 hours of operation until the proper inspection interval is determined according to usage. Check the free movement thereafter, as required, to provide proper clearance between the clutch release bearing and the clutch release levers.

CARE OF THE ENGINE CLUTCH

The engine clutch is designed so that it requires a minimum of attention. It is important however, that a clearance of approximately 1/8-inch be maintained between the engine clutch release bearing and the engine clutch release shaft and release bearing should be lubricated at proper intervals as instructed in the "Lubrication Guide".

ADJUSTING THE ENGINE CLUTCH


The correct free travel can be maintained by loosening cap screw "A" (Illust. 47A) on the outside of the clutch pedal, and rotating the slotted lever at "B" counterclockwise to a position which will give the 1-inch free pedal travel; then retighten the cap screw.



Illust. 47A
Clutch pedal adjustment.

CLUTCH

ADJUSTING THE ENGINE CLUTCH - Continued



Illust. 48
Clutch adjustments.

STORING THE TRACTOR

When your tractor is not to be used for some time, it should be stored in a dry and protected place. Leaving your tractor outdoors, exposed to the elements, will result in materially shortening its life.

Follow the procedure outlined below when your tractor is placed in storage, and repeat steps 1, 5, and 6 every six months thereafter. We also recommend that caution be practiced in starting an engine that has been in storage.

1. Wash or clean and completely lubricate the tractor. See the "Lubrication Guide".

2. Store the tractor so the tires are protected from light. Before storing the tractor,

clean the tires thoroughly. Jack up the tractor so that the load is off the tires when it is to be out of service for a long period. If it is not jacked up, inflate the tires at regular intervals.

3. Run the engine long enough to thoroughly warm the oil in the crankcase. Then drain the oil. Remove the oil filter element. (If any evidence of rust is found on the retaining bolt, clean it thoroughly.) Replace the old filter element with a new one and flush out any sludge from the filter base. Refill the crankcase with fresh oil and run the engine from two to five minutes.

STORING THE TRACTOR

Note: Gum will eventually form in the gasoline fuel tanks, lines, and carburetor if the unit is not used. Gum in carburetor jets and passages affects engine starting. Gum can be dissolved with acetone or a 50-50 mixture of alcohol and benzol.

4. Drain the fuel from the fuel tank and carburetor, and clean out the fuel strainer glass bowl (gasoline engine only).

5. After the engine has cooled off, remove the spark plugs and pour one tablespoonful of SAE-50 lubricating oil of good quality into each cylinder. Crank the engine two or three times to distribute the oil over the cylinder walls. Then replace the spark plugs.

6. Drain and flush the cooling system. -

7. **Tractors with Magneto:** Oil the magneto impulse coupling liberally with very light oil, such as cream separator or sewing machine oil.

8. Remove the valve cover and slush the valves, rocker arms, and push rods with SAE-50 oil. (If any evidence of rust is found, remove it before lubricating.) Use a paint brush to coat the inside of the valve cover with SAE-50 lubricating oil. Replace the valve cover.

9. Remove the oil filler breather cap and oil level gauge. Then plug the oil filler pipe. Also plug the exhaust pipe.

10. Remove the battery and place it on a rack or bench in a cool, dry place above freezing (+32° F.). Check the battery at least once a month for water level and specific gravity.

11. Block the clutch pedal with a wood block so that the clutch is disengaged. This will prevent the clutch facing from sticking to the flywheel or clutch pressure plate.

REMOVING FROM STORAGE

1. Remove the plugs from the crankcase breather cap, the breather pipe and the exhaust pipe.

2. Install a fully charged battery and be sure the proper connections are made. See **Illust. 24A.**

3. Remove the valve cover and slush the valve and valve operating mechanism with a

mixture of one-half kerosene and one-half SAE-10W engine oil.

4. Remove the spark plugs and pour a mixture of one-half gasoline and one-half light lubricating oil into each cylinder; one ounce (two tablespoonfuls) per cylinder is enough.

5. Crank the engine rapidly until excess oil has been blown out of the spark plug holes. This operation will loosen any tight piston rings and wash old, gummy oil from the valves and pistons.

Omit steps 6, 7, and 8 if they were performed before the tractor was stored.

6. Drain the crankcase and flush it out with kerosene or flushing oil and fill with specified lubricating oil. See the "Lubrication Guide".

7. Be sure the lubricating oil filter has a new element before starting the engine.

8. Clean the air cleaner and refill the oil cup.

9. Install the spark plugs after cleaning and setting the gaps.

10. Fill the cooling system. Be sure the cooling system has a rust inhibitor added to it.

11. Fill the fuel tanks.



Caution! Do not accelerate the engine rapidly, or operate it at high speed immediately after starting. Also keep the doors wide open or move the machine outside the storage room immediately to avoid danger from exhaust gas.

12. Start the engine and let it run slowly. If a valve is sticking, pour a small quantity of kerosene on the valve stem until it is loose.

13. Assemble the valve cover.

14. After the engine has been run long enough to clean the excess oil out of the cylinders, the spark plugs should be removed and checked for oil fouling. If fouled, clean and reinstall them in the engine.

15. Remove the block from the clutch pedal.

16. Before driving the tractor, inflate the tires to the correct operating pressures.

COLD WEATHER PRECAUTIONS

When operating the tractor in temperatures of +32 degrees F. or lower, observe the following precautions:

FUEL SYSTEM

Use only a high-test, winter-grade gasoline for starting, and keep your supply in a closed container so the more volatile portion does not evaporate.

Fill the fuel tank at the end of the day's run to prevent condensation in the tank.

LUBRICATION

Be sure to use lubricant of the correct viscosity in the engine crankcase as specified in the "Lubrication Table".

MAGNETO IMPULSE COUPLING (Tractors with Magneto)

For satisfactory starting, it is important to keep the magneto impulse coupling oiled liberally. The impulse coupling should be kept free of dirt and gummy rust formation.

When the engine is hand-cracked, the impulse coupling should trip (click) twice for each revolution of the engine. Failure to do so may indicate the need for cleaning. Refer to pages 26 to 29 for further information.

COOLING SYSTEM

When the temperature is likely to be +32 degrees F. or lower, there is danger of the water freezing in the cooling system.

To prevent this, drain the water from the cooling system at the end of each run or use IH permanent type antifreeze.

Draining and Refilling the Cooling System

If an antifreeze is not to be used:

1. Remove the radiator drain plug on the bottom (center) of the radiator.
2. See that the drain is not clogged and that the water drains completely. Then replace the radiator drain plug.

Note: Before filling the cooling system in freezing weather, cover the front of the radiator. Have sufficient water available at the tractor to fill the cooling system (warm water is preferable). Start the engine, then put the water in immediately. This keeps the water from freezing during warm-up. Maintain the operating temperature of the engine by uncovering as much as necessary of the front of the radiator.

If an antifreeze is to be used:

1. Inspect the hose connections. They must be in good condition both inside and out. Then tighten all water connections.

2. Inspect the fan belt and adjust it, if necessary, to the proper tension. If the belt is worn, or oil-soaked, install a new one.

3. Drain the cooling system as described above. Clean it as described x

4. Check to be sure that the radiator drain plug is tightly closed. Then fill the cooling system, using either of the following procedures:

- a. Make a solution of the required amount of IH permanent type antifreeze with the necessary amount of clean water (use soft or rain water if possible) to fill the cooling system. Fill the cooling system to a level slightly below the bottom of the radiator filler neck, when equipped with a nonpressure-type radiator cap; or to a level approximately 2-inches below the top of the filler neck, when equipped with a pressure-type radiator cap.

- b. Put the required amount of antifreeze into the cooling system. Fill the cooling system with clean water (use soft or rain water if possible) to a level slightly below the bottom of the filler neck, when equipped with a non-pressure-type radiator cap; or to a level approximately 2-inches below the top of the filler neck, when equipped with a pressure-type radiator cap. Start the engine and run it until operating temperature is reached, to allow the antifreeze and water to mix thoroughly.

5. Check the cooling system for leaks, paying special attention to the hose connections.

Antifreeze Solutions

The use of alcohol as an antifreeze is not recommended because denatured alcohol boils at +173 degrees F. However, if it is necessary to use alcohol, check the solution frequently to make certain you have adequate protection for the prevailing temperature.

Note: Use only one type of antifreeze solution. Do not mix solutions, as it will be difficult to determine the exact amount of protection.

Never use any of the following in the cooling water as an antifreeze - honey, salt, kerosene, fuel oil, glucose or sugar, calcium chloride, or any alkaline solution.

TROUBLE SHOOTING

Mechanical Problems and their Probable Cause

If any trouble is experienced, make sure of the cause before attempting to make any adjustments. When making an adjustment, keep in mind the previous setting in case the adjustment doesn't solve the problem.

Possible Cause

Possible Remedy

HARD TO START

No gasoline in starting tank or carburetor	Fill the tank with gasoline; open the fuel shut-off valve. Check the fuel lines, fuel strainer and carburetor.
Fuel strainer or fuel lines clogged	Clean the fuel strainer, check the fuel lines and carburetor.
Impulse coupling inoperative (tractors with magneto).	Flush with kerosene; See page 27.
Water in gasoline	Drain the fuel tank and carburetor. Use new fuel and dry the spark plugs. *
Water in cylinders	Check the cylinder head gasket or look for a clogged drain hole in the exhaust manifold or muffler.
Choked improperly. Flooded engine.	Follow the starting instructions. See pages 9 and 10.
Defective ignition or loose wiring	Check the wiring, plugs, distributor and coil unit, or magneto, etc. See pages 24 to 36.
Defective battery or cranking motor	Check and service; See pages 32 and 33 or replace.
Spark plugs dirty or improper gap.	Clean, adjust the gaps to .023 inch, or replace the plugs.
Magneto grounded (tractors with magneto).	Pull out on the ignition switch. Check for other possible grounds; also see "Magneto" on pages 26 to 29.
Engine speed control not advanced.	Advance the lever one-third for starting.
Lack of compression.	*
Flywheel ring gear teeth broken	*
Lubricating oil of too high viscosity.	Drain and refill with proper lubricant. See the "Lubrication Table" on page 60.
Gears engaged.	Put the gearshift in the neutral position.
Internal seizure.	*

ENGINE OPERATES IRREGULARLY OR KNOCKS

Engine incorrectly timed.	Retime.
Spark plugs dirty; wrong gap or wrong type.	Clean, reset the gaps to .023 inch, or replace.
Poor or weak spark	Check the distributor and coil unit or magneto to see if the spark is good from the coil. Check the breaker points and breaker point opening, spark plugs, and wiring; See pages 24 to 36.
Carburetor setting incorrect	Adjust; see "Carburetor" on page 11.
Poor grade fuel or water in fuel	Drain and use a good grade of clean fuel.
Engine overheating	Check the cooling system and fan belt; adjust the radiator shutter if used; see "Engine Overheats" on page 52.
Engine valves at fault	Check the valve clearance. *
Air leaks around intake manifold.	Check the gasket and tighten the nuts.
Engine smokes.	Check the air cleaner oil level. Check the fuel delivery at the carburetor. Check for worn piston and rings. *
Excessive carbon in engine	*
Loose piston pin or bearings	*
Broken rings or loose pistons.	*
Worn connecting rod and main bearings	*
Governor sticking or needs adjustment.	*

* See your International Harvester dealer.

TROUBLE SHOOTING

Possible Cause

Possible Remedy

LACK OF POWER

Engine speed control lever not advanced.	Advance the engine speed control lever.
Engine cold or overheated.	Run the engine until it warms up before putting it under load. Check the cooling system. *
Engine overloaded.	Reduce the load.
Engine knocks excessively.	Use good fuel; also check the timing. *
Governor not working properly.	*
Poor compression.	Service the valves and piston rings. *
Poor fuel or too lean a mixture.	See "Carburetor" on page 11.
Fuel lines or strainer obstructed.	Clean; See page 10.
Fuel tank air vent closed.	Open the vent in the cap.
Exhaust pipe clogged.	Clean out.
Air cleaner clogged or air leakage between carburetor and engine.	Clean the air cleaner as instructed on pages 23 and 24. Tighten the carburetor and manifold mounting nuts.
Oil of too high viscosity in crankcase or air cleaner.	Drain and refill with proper lubricant. See the "Lubrication Table" on page 60.
Incorrect timing or faulty ignition.	See "Distributor and Coil Unit" on pages 29 and 30 or "Magnet" on pages 26 to 29.
Clutch slipping.	Adjust the free travel of the pedal; see pages 47 and 48.
Brakes drag.	Adjust the brakes; see pages 46 and 47.
Carburetor intake manifold or cylinder head intake ports restricted by carbon.	Clean. *

ENGINE OVERHEATS

Cooling system clogged or limed.	Clean the system; see page 21.
Fan belt slipping.	Adjust or replace the belt; see page 22.
Insufficient water in cooling system.	Fill the radiator to the proper level; see page 20.
Radiator cores clogged.	Remove all chaff or dirt from the radiator grille; clean with forced air or water.
Wrong kind of fuel.	Change to a good grade of gasoline.
Carburetor improperly set.	See "Carburetor" on page 11.
Timing incorrect.	Check "Distributor and Coil Unit" on pages 29 and 30 or "Magnet" on pages 26 to 29.
Breaker point opening incorrect.	Adjust the opening; see "Distributor and Coil Unit" or "Magnet" on pages 26 to 30.
Excess load.	Reduce the load.
Excess carbon in engine.	*
Heat indicator defective (distillate engine).	Replace the heat indicator. *

NO OIL PRESSURE, TOO HIGH OR TOO LOW

Defective oil pressure indicator.	Replace. *
Wrong viscosity, diluted or insufficient oil.	See the "Lubrication Table" on page 60. Check the oil level; if diluted, replace with fresh oil.
Broken, loose or plugged oil lines.	Clean and tighten. *
Low oil level in crankcase.	Add oil; see the "Lubrication Guide." Check for an oil leak.
Defective or dirty oil pressure regulating valve.	*
Oil pump strainer clogged or pump not working.	Clean as instructed on pages 57 to 59.
Worn bearings.	*

Continued on next page.

* See your International Harvester dealer.

TROUBLE SHOOTING

Possible Remedy

Possible Cause

OIL DILUTION OR USES TOO MUCH OIL

Oil of incorrect viscosity.	See the "Lubrication Table" on page 60.
Leaks in oil lines or filter or in oil pan plug or gasket	Check and tighten. *
Worn piston or oil rings	*
Loose connecting rod bearings	*
Long engine idling	Stop the engine.
Engine overheating or too cold	See "Lack of Power" and "Engine Overheats"; see page 52.
Engine speed too high	*
Crankcase breather clogged.	Clean. See page 56.

USING TOO MUCH FUEL

Fuel mixture too rich..Carburetor out of adjustment.	Check choke and see "Carburetor" on page 11.
Fuel leaks.	Tighten or replace the fuel lines or fuel strainer gasket.
Poor grade of fuel	Use a good grade of gasoline.
Choke closed.	Investigate for the choke not operating.
Engine overloaded	Reduce the load or shift to a lower speed.
Poor compression	*
Faulty ignition.	x
Engine not operating at proper temperature	Check the cooling system. Check the lubricating oil. *
Air cleaner clogged	Service the air cleaner; see pages 23 and 24.
Wrong viscosity or amount of lubricating oil.	See the "Lubrication Table" on page 60 and keep the oil up to the proper level.

NO FUEL AT CARBURETOR

Fuel low in tank.	Fill the fuel tank and check the fuel lines.
Air vent hole in fuel tank cap plugged up.	Clean out the vent hole.
Fuel valve closed or partly open.	Open the valve; see the starting instructions.
Dirty or clogged fuel strainer screen or line.	Clean as instructed on page 10.

IGNITION AND ELECTRICAL

Wrong kind, old, cracked, dirty, or poorly set spark plugs.	Clean and set the gaps to .023 inch, or replace with new plugs.
Loose wiring or improper connections.	Check the wiring to see that all connections are clean and tight; see pages 34 to 36.
Distributor and coil unit or magneto not timed correctly	Retime as instructed on pages 26 to 30.
Distributor cap or rotor or breaker chamber dirty	Clean as instructed on pages 29 and 30.
Breaker points dirty, pitted or improperly set.	Clean and reset the opening or replace with new points; on pages 29 and 30.
Breaker arm stuck, weak or broken spring.	Check and replace; see pages 29 and 30.
Impulse coupling dirty (tractors with magneto).	Clean and lubricate as instructed on page 27.

* See your International Harvester dealer.

Possible Cause

Possible Remedy

IGNITION AND ELECTRICAL - Continued

Battery defective, low charge or loose connections	Recharge, clean and tighten the cable lugs or replace with new; check the ground cable; see pages 32 and 33.
Cranking motor failure	Replace. *
Generator inoperative	Clean the commutator, check the brushes; see page 31.
Voltage regulator or generator relay	*
Charge indicator inoperative	Replace the charge indicator. *
Charge indicator shows discharge	Check the battery and generator; check the drive belts and wiring.
Lights will not burn	Check the battery ground cable. Turn on the switch, replace the sealed beam units, replace the fuse, recharge the battery, or check the wiring and generator. *
Lights burn dim	Turn the switch to bright. Recharge the battery, tighten the cable terminals, check the sealed beam units, clean the contacts.

BRAKES

Do not hold	Adjust the brakes; see pages 46 and 47 for new lining needed. *
Drag or uneven	Adjust the brakes; see pages 46 and 47.
Grease on lining	Replace the lining. *
Return spring broken	Replace.
Do not release	Release the brake lock. Be sure the left brake cross shaft is free to turn.

TRANSMISSION, BELT PULLEY AND POWER TAKE-OFF

Hard to shift gears	Use lubricant of the correct viscosity; see page 60.
Shifter fork or lever defective	Replace. *
Engine clutch drags	See "Lack of Power."
Gears clashing	Stop the tractor and disengage the clutch before shifting the gears.
Gears slipping out of mesh	*
Noisy	Check the oil level; use lubricant of the proper viscosity. *
Damaged parts	*

REAR WHEELS

Do not turn	Release the brake lock. Transmission, differential or clutch faulty. See the transmission section above. *
-----------------------	--

FRONT WHEELS

Too tight or too loose	Check the lubricant in the bearings, check the bearing adjustment; see page 59.
Lubricant leakage	Check the oil seal. *

Continued on next page.

* See your International Harvester dealer.

TROUBLE SHOOTING

Possible Cause

Possible Remedy

STEERING

Faulty	Check the steering worm and gear; check the front axle adjustment; see pages 39 and 40. Check the lubricant in the front wheel. Check the tire inflation. *
Defective front axle	Inspect the linkage, check and replace faulty parts. *
Tractor turns to one side.	Check and adjust the brakes evenly; see pages 46 and 47. Check the pneumatic tire air pressures. Check the front axle adjustment; see pages 39 and 40.

PNEUMATIC TIRES

Excessive or uneven wear	Check for toe-in; see page 40. Check the air pressure and load on the tires.
Slippage, rear tire.	Add more weight, and check for high air pressure; see pages 45 and 46. If the tread is badly worn, the tires may slip more readily. Replace with new tires or use lug-type chains.

FARMALL TOUCH-CONTROL SYSTEM

Maintenance	See detailed instructions on pages 13 and 14.
-------------------	---

* See your International Harvester dealer.

LUBRICATION

The life of any tractor depends upon the care it is given. Proper lubrication is a very important part of that care.

Tractors shipped to destinations in United States of America, Canada, and Mexico have the crankcase and air cleaner filled with a light grade of oil for faster run-in. If the engine is to be operated at temperatures between +75°F. and +10°F., this oil can be used. If temperatures are not within the range specified, drain the oil from the crankcase, oil filter, and air cleaner, and replace it with the required amount of fresh oil having the physical properties and proper viscosity for the prevailing temperature and type of service. After the first 50 hours of operation, the oil filter element and crankcase oil should be replaced. Refer to the "Lubrication Guide".

The engine has a pressure-feed lubrication system. A gear-type oil pump circulates the


lubricating oil under pressure to the crankshaft bearings, connecting rod bearings, camshaft bearings, valve mechanism, and timing gears thereby assuring positive lubrication of all parts.

The oil pressure gauge indicates whether lubricating oil is circulating through the engine. Refer to page 6 for further information.

The engine is equipped with an oil filter which continually cleans the oil while the engine is running. To obtain the full benefit from the filter, replace the used element with a new one, everytime the oil in the crankcase is changed. (After every 250 hours of operation). Cleaning the oil element is not satisfactory.

LUBRICATION

CRANKCASE BREATHER AND OIL FILLER CAP



Illust. 56

Checking the oil level in the crankcase.

The crankcase oil filler cap has a bayonet-type oil level gauge attached to it. The oil level should never be above the "FULL" mark or below the "LOW" mark on the gauge. When checking the oil level (Illust. 56), the gauge must be withdrawn and wiped clean, then inserted all the way and withdrawn for a true reading.

Do not run the engine for any length of time with the oil level below the low mark on oil level gauge. See Illust. 56.

Never check the oil level while the engine is running.

OIL PUMP

The gear-type oil pump in the crankcase has a screen attached to the oil intake which stops large dirt particles from entering the oiling system. Clean this screen whenever the oil pan is removed.

ENGINE OIL

The three types of crankcase oils marketed have been classified by the American Petroleum Institute (API) as "For Service ML", "For Service MM", and "For Service MS".

Either single or multi-viscosity oils designated "For Service MS" are recommended for this engine.

TO AID STARTING

To facilitate starting, the selection of crankcase lubricating oils should be based on

the lowest anticipated temperature for the day. It is not necessary to change the crankcase oil every time the temperature rises or falls into another temperature range during some part of the 24-hour day.

Note: After changing oil, the engine must not be operated at high speed or under load until the new oil has had ample time to reach all bearings.

After changing to a lighter grade of oil, the engine must be operated at least five to ten minutes without load so the lighter oil is worked into the bearings and onto the cylinder walls.

Also see "Cold Weather Precautions" on page 50 for special instructions.

GEAR LUBRICANT

Tractors shipped from the factory to destinations in the United States of America, Canada, and Mexico are filled with lubricant in the transmission, differential and steering gear housing. Tractors shipped for export have all lubricant drained.

Use only high-quality lubricating oils and greases as specified in "Lubrication Table". For your own protection, select only oils and greases of recognized manufacture.

LUBRICATION FITTING GREASE

Use chassis lubricant (pressure-gun grease) for lubrication fittings on which the hand lubricator is applied.

Note: Keep your supply of lubricating oil and grease absolutely clean and free from dust. Always use clean containers. Keep the lubricator clean and wipe dirt from the fittings before applying the lubricator.

OIL FILTER

The life of your engine depends upon clean oil being circulated to all bearings.

The purpose of the oil filter is to separate and remove the dirt and other foreign substances from the oil to prevent these injurious materials from being circulated to the engine. This filter will keep the circulating oil free of harmful materials. Under normal operating conditions, replace the filter element every 250 hours of operation.

LUBRICATION

OIL FILTER - Continued

If the element is not serviced and becomes clogged, the element by-pass valve will open and unfiltered oil will be circulated through the engine.

Note: To avoid delays, carry extra filter elements on hand so replacement can be made at the proper time.

Changing the Filter Element

Do not change the element while the engine is running.

1. Remove the oil filter drain pipe cap (Illustr. 57A) and allow the oil filter to drain completely.
2. Clean off filter cover "A" (Illustr. 58) to prevent dirt from dropping into the filter when the cover is removed.


3. Unscrew and remove bolt "B" and gasket "C" (Illustr. 58).

4. Lift up and remove filter cover "A" and gasket "D" (Illustr. 58).


5. Remove the old element.

6. If the oil appears very dirty or sludgy when draining, flush out the filter case with kerosene. Before flushing, however, replace the bolt without the filter cover in order to prevent sludge from being flushed into the crankcase. When completely flushed and drained, replace the drain pipe cap.

7. Inspect the small metering hole at the threaded end of the oil filter retainer bolt, and make sure it is not plugged. A plugged metering hole will impair or stop all oil flow through the oil filter element.



Illustr. 57
Diagram of oil flow through the filter.




Illustr. 57A
Installing the new oil filter element.

LUBRICATION

OIL FILTER - Continued

Changing the Filter Element - Continued



Illust. 58
Oil filter assembled.

8. To install the new filter element, move gasket "C" up to the top of bolt "B" and place cover "A", gasket "D" and the new element on the bolt in their proper order. See Illust. 58. Then install the entire assembly and be sure that filter cover gasket "D" seats properly. Screw the bolt into the filter base and tighten securely.

9. Check the oil level in the crankcase to see that the new oil is up to the proper level (see "Lubrication Guide"). Now start up the engine, check the oil pressure gauge to see whether lubricating oil is circulating through the engine, and inspect the filter for oil leaks.

TOUCH CONTROL SYSTEM

Fluid Level

When the Touch-Control system is filled to the proper level with IH Hy-Tran® Fluid, it should not require servicing, unless for some reason the system has been disturbed.

If the Touch-Control system should fail to operate in a satisfactory manner, check to see if there are any noticeable leaks in the system, also check the fluid level in the reservoir, or see your International Harvester dealer.

Before removing the filler plug (Illust. 13) for inspection, thoroughly clean the plug and surrounding area of all dirt and grit.

The correct fluid level is to the bottom of the filler opening. If it is necessary to add fluid, use IH Hy-Tran Fluid. It is essential that the fluid be absolutely clean and free from water and all foreign matter when placed in the system. Cloudiness may indicate the presence of moisture.

Never operate the tractor without having sufficient fluid in the reservoir. Insufficient fluid may cause damage to the Touch-Control system.

Draining and Filling the Reservoir


Normally it is not necessary to drain the reservoir at any given time interval. If it becomes necessary to drain the system for any reason, such as disassembly, flushing the system, etc., proceed as follows:

1. Wipe off all dirt and grit from the reservoir and filler plug.

2. Remove the filler plug (Illust. 13) and the drain plug (Illust. 58A) and place them in a clean container.

When the fluid has stopped draining, run the engine very briefly to drain the fluid from the pump and connecting pipes.

To clean the strainer, first wipe off all dirt and grit from the cylinder block. If your tractor is equipped with a radiator shutter, disconnect the radiator shutter control rod. Then remove the heat indicator element from the strainer by screwing out the element nut.



Illust. 58A
Right side of Touch-Control system.

Continued on next page.

LUBRICATION

TOUCH CONTROL SYSTEM - Continued

Draining and Filling the Reservoir - Continued.

Now remove the four cap screws which hold the strainer to the cylinder block, and pull out the screen. Clean the strainer thoroughly in clean IH Hy-Tran Fluid.

Then replace the strainer and make sure the gasket is in perfect condition. If the gasket is damaged, replace it with a new one.

Replace the heat indicator element and tighten the element nut sufficiently to prevent leakage of IH Hy-Tran Fluid.

The refill capacity of the Touch-Control system, when drained as instructed above, is 3-1/2 U.S. pints.

Note: If it is necessary to flush the system, use IH Hy-Tran Fluid so the necessary lubrication of the pump and control system is maintained without adulteration. Never use any other oil.

3. After the system has drained completely, replace the drain plug and fill the reservoir to within 1/2-inch of the bottom of the filler opening with IH Hy-Tran Fluid.


5. Add sufficient clean fluid to the reservoir to bring the fluid level to within 1/2-inch of the bottom of the filler opening. Replace and tighten the filler plug.

The capacity of a completely dry unit (when a new or rebuilt unit is installed) is 4-1/4 U.S. pints.

GREASING THE FRONT WHEELS

Every six months or after every 500 hours of operation, whichever occurs first, remove, clean and repack the front wheel bearings.

Raise the front end of the tractor until the wheel clears the ground and remove the wheel as shown in **Illust. 59**. Unscrew hub cap "A" (**Illust. 59A**), remove the cotter pin, and remove nut "B" and washer "C". Remove bearing "D" and place it in hub cap "A" or a clean container.




Illust. 59
Front wheel removed from hub.

Clean the inside of hub "E", remove the old grease from the bearings, clean them with kerosene, and repack with fiber grease.

It is advisable to leave bearing "F" on the axle and clean it with a brush and kerosene. Repack the rollers with new grease before re-assembling the bearings.

Inspect the oil seal felt washer and gasket and if they are not in satisfactory condition, replace them with new ones. A dirt deflector is also provided on the axle to prevent dirt from entering at the inner bearing.

Reassemble the wheel and tighten nut "B" until the wheel binds slightly, rotating the wheel at the same time. Back the nut off one castellation from the cotter pin hole; replace the cotter pin and hub cap.



Illust. 59A
Front wheel hub and bearing removed for cleaning.

LUBRICATION TABLE


Point of Lubrication	Capacity	Anticipated Air Temperature				
		Above + 90° F.	+90° F. to + 10° F.	+32° F. to + 10° F.	+10° F. to — 10° F.	Below — 10° F.
Engine crankcase	3 qt.	SAE-30 or SAE 20W-40	SAE-20 or SAE 10W-30*	SAE-10W or SAE 5W-20	SAE 5W-20 or 2-3/4 qt. SAE- 10W w/1/2 pt. kerosene	2-1/2 qt. SAE-10W w/1 pt. kerosene
Air cleaner oil cup Donaldson type United type	1/2 pt. 3/8 pt.				SAE-10W or SAE 5W-20	
Magneto (if so equipped) Rotor bearing Impulse coupling	x x x x x x	SAE-30 Light oil, i.e.,	SAE-30 cream separator or sewing, machine oil	SAE-20	SAE-10W Kerosene	
Battery ignition unit (if so equipped) Distributor and drive housing Cam hole felt (in distributor)	x x x x x x	Chassis lubricant - Light engine oil				
Generator	x x x	SAE-20 engine oil				
Transmission	3-1/2 pt.	Tractors operating in temperatures below +40 degree F., IH Hy-Tran® Fluid; or SAE-80 gear lubricant may be used. If temperatures are consistently above +40 degree F., IH Hy-Tran Fluid; or SAE-90 gear lubricant may be used.				
Rear axle housing	1-3/4 pt.					
Belt pulley housing	1/3 pt.					
Steering gear housing	3/4 pt.	IH Torque Amplifier Transmission Lubricant Additive; or worm gear lubricant.				
Touch-Control reservoir	4-1/4 pt.	IH Hy-Tran Fluid.				
Lubrication fittings	x x x	Use chassis lubricant (pressure-gun grease) for fittings on which the hand lubricator is applied.				

*SAE 5W-20 may be used if temperatures are not consistently above +65 degrees F.

LUBRICATION GUIDE

The symbols around the reference numbers indicate the intervals of lubrication.

▲ — 10 hours, ● — 50 hours, ◆ — 150 hours, ■ — 250 hours, ■ — 500 hours, ● — periodic




B-12000C

Illustr. 61
Side view of tractor.

LUBRICATION GUIDE

The symbols around the reference numbers indicate the intervals of lubrication.

▲ — 10 hours, ● — 50 hours, ◆ — 150 hours, ■ — 250 hours, ■ — 500 hours, ● — periodic



B-12889

Illust. 62
Fast-Hitch

LUBRICATION GUIDE

The symbols shown around the reference numbers in Illusts. 61 and 62 indicate the intervals of the lubrication. Paragraph numbers correspond to reference numbers in the illustrations.

— Daily or After 10 Hours of Operation

1. Crankcase oil level gauge and filler cap.

Check the oil (with the engine stopped) and add sufficient new oil to bring it to the "FULL" mark on the bayonet gauge. Do not check the oil level while the engine is operating or operate the engine if the oil level is below the "LOW" mark on the bayonet gauge. If the oil level is checked after the engine has been stopped for some time, the oil level may show slightly above the "FULL" mark on the gauge. This is a normal condition as the result of oil draining back from the filter.

2. Air Cleaner.

Clean and refill the oil cup to the oil level bead with the same new oil as used in the engine crankcase.

3. Steering knuckle post (2).

4. Tie rod (2).

5. Tie rod ball seat.

6. Front axle pivot shaft.

7. Steering shaft support bracket.

Use chassis lubricant (pressure-gun grease) and apply two or three strokes of lubricator, or sufficient grease to flush out the old grease and dirt. Lubrication points are the same for both fixed and adjustable front axles.

Fast-Hitch

8. Rockshaft plate bracket (2).

9. Rockshaft arm swivel (2).

10. Lateral link swivel, upper (2).

11. Leveling screw housing (1).

12. Lateral link swivel, lower (2).

13. Depth adjusting screw housing (1).

Use chassis lubricant (pressure-gun grease) and apply sufficient lubricant to flush out the old grease and dirt.

— Weekly or After 50 Hours of Operation

14. Touch-Control rockshaft arms.
15. Clutch pedal shaft

Use chassis lubricant (pressure-gun grease) and apply two or three strokes of lubricator, or sufficient grease to flush out the old grease and dirt.

16. Seat spring.

Use an oil can and put a few drops of engine oil in the oil hole (16) in the seat spring retainer.

Miscellaneous parts

Lubricate the clutch and brake pedal connections with a few drops of engine oil.

LUBRICATION GUIDE

— After Every 150 Hours of Operation

17. Power take-off shaft.

Use chassis lubricant (pressure-gun grease) and apply one or two strokes of the lubricator.

— After Every 250 Hours of Operation

18. Crankcase oil pan.

While the oil is warm, remove the drain plug and drain all of the oil from the crankcase pan. Replace the drain plug. Remove the crankcase filler cap (1). Refill the crankcase pan with new oil up to the "FULL" mark on the oil level gauge. Refer to the Lubrication Table.

19. Oil filter drain.

20. Oil filter element.

Replace the oil filter element every time the crankcase oil is changed. Remove the pipe cap (20) and allow all the oil to drain out. Remove the oil filter bolt (21) and the filter cover, and remove the used filter element. If the oil appears very dirty or sludgy when draining, flush out the filter case with kerosene. Before flushing, however, replace bolt (21) without the filter cover in order to prevent sludge from being flushed into the crankcase. Replace the drain cap (20) and install the new filter element.

— Every Six Months or After Every 500 Hours of Operation

21. Generator oil cups (2).

Insert the oil can spout through the holes in the hood above each oil cup. Lift the cap on each oil cup and place 8 to 10 drops of oil in each cup.

Note: Overlubricating will "gum" the commutator, resulting in reduced output and increased wear. Never oil the commutator and do not lubricate the generator while it is in operation.

22. Fan hub.

Turn the fan hub so oil retainer screw (22) is to the right horizontal position. Remove the screw and fill the hub with engine oil to the level of the filler hole opening. Now turn the fan hub so the oil filler hole is on the bottom to allow excess oil to drain off. Replace the oil retainer screw.

23. Magneto.

Fill rotor bearing oil cup (23) once with the same oil used in the engine crankcase.

24. Distributor (battery ignition unit).

Remove the grease plugs and insert lubrication fittings. Apply chassis lubricant (pressure-gun grease) to the distributor fitting until a small quantity comes out of the relief hole opposite the plug. Apply several strokes of the lubricator to the drive housing fitting.

Remove the distributor cap and the distributor rotor, and apply one or two drops of light engine oil to the felt in the hole at the end of the breaker cam.


25. Front wheels.

Remove, clean, and repack the front wheel bearings with fiber grease.

26. Clutch release bearing.

Use pressure-gun grease (chassis lubricant). After every 1,000 hours or at least once every year, apply a few strokes of the lubricator to clutch release bearing fitting (26) or just enough grease until it starts to come out of the bleeder hole on top of the bearing retainer. To reach the fitting, remove the clutch housing handhole cover "A".

LUBRICATION GUIDE



- Periodic

Transmission

- 27. Oil filler plug.
- 28. Oil level plug.
- 29. Oil drain plug.

Check the oil level periodically. Keep the lubricant up to level plug (28) on the left side of the transmission case. Change the oil in the transmission case at least once a year, preferably before freezing weather sets in. However, do not drive the tractor more than 1,000 hours without changing the oil. Remove drain plug (29) and allow all oil to drain out. Replace the drain plug and remove filler plug (27) and level plug (28). Refill with approved lubricant up to the level plug opening and replace the plugs. Refer to the Lubrication Table for the approved lubricant and capacity.

Belt Pulley Housing

- 30. Filler plug.
- 31. Level plug.
- 32. Drain plug.

Check the oil level periodically. Use approved lubricant (see the Lubrication Table) and keep the lubricant up to the level plug (31). Drain and refill the housing each time the oil is changed in the transmission case. To change the oil, remove the drain plug (32) and allow all the oil to drain. Then replace the drain plug. Remove filler plug (30) and level plug (31). Fill to the level plug opening and replace the plugs.

Rear Axle Housing

- 33. Oil filler and level plug (2).
- 34. Oil pan (2).

Check the oil level periodically. Keep the lubricant up to level plug (33) in each rear axle housing. Remove the drawbar to get at the level plug in the left housing. Change the oil at least once a year. However, do not drive the tractor more than 1,000 hours without changing the oil. To drain, remove rear axle housing pan (34). Clean the pan and replace it. Remove plug (33) and fill up to this level with approved lubricant. Replace the plug. Refer to the Lubrication Table for the approved lubricant and capacity.

Steering Gear Housing

- 35. Filler plug.
- 36. Level plug.
- 37. Drain plug.

Check periodically and add sufficient approved lubricant to the level of plug (36). Remove filler plug (35) and level plug (36) and fill with approved lubricant to the level plug opening. Replace the plugs. Refer to the Lubrication Table for the approved lubricant and capacity.

Magneto Distributor Gear

{ Every year or 2,000 hours repack with IH magneto grease.

Miscellaneous Parts

{ Occasionally put a few drops of engine oil on the engine control linkage, such as the engine speed control rod, governor connections, etc.

SPECIFICATIONS

CAPACITIES (Approximate-U.S. Measure)

Fuel tank	7-1/2 gal.
Water cooling system	9-3/4 qt.
Crankcase pan	3 qt.
Transmission case	3-1/2 pt.
Rear axle drive housing (each)	1-3/4 pt.
Steering gear housing	3/4 pt.
Air cleaner oil cup (Donaldson)	1/2 pt.
Air cleaner oil cup (United)	3/8 pt.
Belt pulley housing	1/3 pt.
Touch-Control system	4-1/4 pt.

ENGINE

Cylinders	4
Bore	2-5/8-in.
Stroke	2-3/4-in.
Engine speed (governed)	
Minimum speed	450-500 rpm
Maximum idle speed (no load)	2,016 rpm
Maximum (full load)	1,800 rpm
Magneto (clockwise rotation)	IH, Type J-4
Spark plug gap023-in.
Valve clearance (engine cold)013-in.
Carburetor	IH, 3/4-in. updraft
Battery ignition unit (when so equipped) (16° advance distributor)	IH


TRANSMISSION (Three Speeds)

(Speeds based on 8-24 pneumatic tire size)

Speed: 1st	2.4 mph
2nd	3.2 mph
3rd	7.3 mph
Reverse	2.7 mph

POWER TAKE-OFF SHAFT SPEED (Counterclockwise Rotation)

Low idle (no load)	475 rpm
Fast idle (no load)	2,015 rpm
Maximum (full load)	1,800 rpm



The power take-off shaft connection is a 15/16-inch pitch diameter, ten-tooth involute spline with a 30 degree pressure angle, machined for outside diameter fit. The dimensions are shown in Illust. 67.

Illust. 66
Power take-off shaft spline dimensions.

SPECIFICATIONS

BELT PULLEY

Pulley speed	
Low idle (no load)	392 rpm
Fast idle (no load)	1,665 rpm
Maximum (full load)	1,487 rpm
Belt speed (6-in. pulley)	2,336 ft. per min.
(7-5/8-in. pulley) *	2,968 ft. per min.
(9-in. pulley)	3,504 ft. per min.
Pulley diameter :*.	6 in., 7-5/8 in., 9-in.
Pulley face	4-3/4-in.

ELECTRICAL SYSTEM

Fuse (cartridge-type)	SFE—20 amp
Headlight or rear light sealed beam unit.	6-8 volt

CLUTCH

Single-plate, dry-disc, spring-loaded	6-1/2 in.
---	-----------

FOOT BRAKES

External contracting on drums.

WHEELS AND TREAD

Front wheels, pneumatic tire size.	†4.00—12
Rear wheels, pneumatic tire size	†8.3—24
Wheelbase.	69-1/4 in.
Tread, front (standard—fixed axle with reversible wheels)	40-5/8 and 46-3/8-in.
Tread, front (adjustable front axle, 4-in. intervals)	40-5/8 to 56-5/8-in.
Tread, rear (adjustable—reversible wheels and rims, 4-in. intervals)	40 to 56-in.

† Other pneumatic tire sizes are available.

* Regularly supplied with belt pulley.

GENERAL

Length, over-all	99-3/8-in.
Width, over-all—minimum treads	48-1/4-in.
Width, over-all—maximum treads	64-1/4-in.
Height, over-all (to top of steering wheel)	62-3/4-in.
Ground clearance for crops: Under front axle.	20-3/8-in.
Under rear axle	20-3/4-in.
Quick-attachable drawbar (adjustable):	
Normal height	14-3/8-in.
High and low positions.	12-3/8 and 16-in.
Lateral adjustment	11-3/8-in. on each side of center hole
Fast-Hitch drawbar: Height above ground	7 to 22-in.
Lateral movement	9-1/2-in.
Swinging drawbar: Height above ground	13, 16, 18-1/2-in.
Lateral swing	28-in.
Minimum turning radius with minimum treads:	
With brake applied	8-1/4 ft.
Without brake applied	9-1/4 ft.

EXTRA EQUIPMENT AND ACCESSORIES

The tractor is used for so many different types of work and is called on to operate under so many different conditions that a considerable variety of equipment is necessary to adapt it to the varied requirements of the user.

When you purchased your tractor, you probably had it completely equipped for your particular needs at that time. However, later you may wish to obtain some of the equipment or accessories listed below. These items can be purchased from and installed by your International Harvester dealer.

Type of Equipment	Type of Equipment
Belt Pulley and/or Power Take-Off	Pull Bar Extension (Tractors with Fast-Hitch)
De Luxe Upholstered Seat	Rear Wheel Weights
Detachable Seat Pads	Tachometer
Fast-Hitch	Tire Pump for Pneumatic Tires
Front Axle, Adjustable	Tire Pump Kit for Pneumatic Tires
Front Wheel Weights	Touch-Control
High Altitude Cylinder Head	Valve Rotators
Horn	

INDEX

Description	Page No.	Description	Page No.
Adding water to the cooling system (When equipped with pressure- type radiator cap)	20, 21	Engine oil	56
Adjustable wide tread front axle . . .	39, 40	Engine speed control lever	5
Adjusting the drawbar	17	Engine speeds	66
Adjusting the engine clutch	47, 48	Extra equipment and accessories . .	69
Adjusting the idle adjusting screw . .	11	Fan belt tension	22
Adjusting the seat	11	Fan hub lubrication	23
Adjusting the tread widths	41	Fast-Hitch	14 to 16
After the engine starts	10	Fast-Hitch load limitations	16
Air cleaner oil cup	8	Filling the cooling system	20
Air cleaning system	23, 24	Filling the fuel tank	8
Air in the system	14	Front axle, adjustable type	40
Air intake cap and screen	24	Front wheels	39, 40
Before starting the tractor	7	Front wheel weights (one piece) . .	43
Belt pulley and power take-off	18, 19	Front wheel weights (two piece) . .	43, 44
Belt pulley and power take-off shifter rod	6	Fuel system (Gasoline)	{ 7, 10, 11, 50
Brakes	46, 47	Fuel tank	8
Brake adjustment	46, 47	Fuse	32
Brake pedals	5	Gasoline engine	9, 10
Brake pedal latch	5	Gauges (meters and indicators) . .	6, 7
Brake pedal lock	5	Gear lubricant	56
Carburetor	11	Gearshift lever	5
Carburetor choke lever	5	General precautions	24
Care of the engine clutch	47	Generator and regulator	31
Care of tires	45	Generator belt	23
Changing from belt pulley to power take-off	19	Generator belt tension	31
Changing from power take-off to belt pulley	19	Governor	6
Charge indicator	6	Greasing the front wheels	59
Choke rod	5, 9	Headlights	31
Cleaning the cooling system	21, 22	Hitch adjustments	16
Cleaning the fuel strainer and sediment bowl	10	Hitching trailing equipment to the tractor	17
Clutch	47, 48	Ignition coil	31
Clutch pedal	5	Ignition switch button	6
Cold weather precautions	50	Inflation, tire	45
Combination rear light and taillight .	32	Instruments and controls	4 to 6
Contents, table of	1	Introduction	2 to 4
Cooling system	20 to 23, 50	Lighting switch	6
Coupling the equipment (Fast-Hitch) .	16	Locking the brakes	12
Crankcase breather and oil filler cap	56	Lubrication	{ 7, 51, 55 to 59
Crankshaft bearings, pistons, and rings	37	Lubrication fitting grease	56
Cylinder head gasket	37	Lubrication guide	61 to 65
Distributor and coil unit	29, 30	Lubrication table	60
Driving the tractor	11, 12	Magneto	26 to 29
Electrical system	24 to 36	Magneto impulse coupling (Tractors with magneto)	50
Engine cooling system	7	Minor engine service operations . .	37, 38
		Mounting tires on the rim	46

INDEX

Description	Page No.	Description	Page No.
Oil cup service	23	Starting switch control rod	6, 8
Oil filter	56 to 58	Starting the engine	9, 10
Oil pressure gauge	6, 10	Starting the tractor	11, 12
Oil pump	56	Steering the tractor	12
Operating pressure for low-pressure tractor tires	45, 46	Stopping the engine	10
Operating the belt pulley or power take-off with the tractor standing still	18	Stopping the tractor	12
Operating the power take-off with tractor in motion	19	Storage battery	32, 33
Overloading	46	Storing the tractor	48, 49
Pneumatic tires	7, 45, 46	Table of contents	2
Polarizing the generator	31	Tachometer drive unit	38
Power timing light	31	Taillight	32
Preparing for each day's work	8	Tire chains	46
Pull bar extension (Fast-Hitch)	16	To aid starting	57
 		Touch-Control system	58, 59
Radiator core	22	Towing the tractor	12
Rear wheels	41, 42	Traction and weights	46
Rear wheel weights	44	Trouble shooting	51 to 55
Removing from storage	49	 	
Removing the drawbar	17	Using the spark plug tire pump ..	45
Rust prevention	21, 22	 	
 		Valve clearance adjustment	37, 38
Shipping tractors equipped with pneumatic tires	45	 	
Spark plugs and cables	25, 26	Washing the cleaner	24
Specifications	66, 67	Weights	43, 44
		Wheels	40 to 43
		Wheels, front tread	40
		Wheels, rear tread	42, 43
		Wheel weights	46



Accidents can be prevented with your help

No accident-prevention program can be successful without the wholehearted co-operation of the person who is directly responsible for the operation of equipment.

To read accident reports from all over the country is to be convinced that a large number of accidents can be prevented only by the operator anticipating the result before the accident is caused and doing something about it. No power-driven equipment, whether it be transportation or processing, whether it be on the highway, in the harvest field or in the

industrial plant, can be safer than the man who is at the controls. If accidents are to be prevented—and they can be prevented—it will be done by the operators who accept a full measure of their responsibility.

It is true that the designer, the manufacturer, the safety engineer can help; and they will help, but their combined efforts can be wiped out by a single careless act of the operator.

It is said that "*the best kind of a safety device is a careful operator.*" We ask you to be that kind of an operator.

As a member of the National Safety Council, we are privileged to use the Green Cross for Safety to designate not only our interest in Safety, but to point out more clearly the safety precautions in this manual.

NATIONAL SAFETY COUNCIL



The Symbol of Quality Products

Backed By A Dealer Organization
Equipped To Give You —

Service Where You Need It

District Offices in the United States

Amarillo, Tex.

714 East 10th St.
P.O. Box 1071
Tel. DRake 3-3373

Atlanta 3, Ga.

580 Whitehall St., S. W.
P.O. Box 4838
Atlanta 2, Ga.
Tel. MUrray 8-4440

Baltimore 5, Md.

6501 Quad Ave.
Tel. 327-3900

Billings, Mont.

20 South Broadway
P.O. Box 2515
Tel. 245-4144

Broadview, Ill.

1301 West 22nd St.
P.O. Box 126
Tel. FILLmore 3-3800

Camden, N. J.

Suckle Ave. and
National Rd.
Pennsauken 11, N. J.
P.O. Box 1928
Camden 1, N. J.
Tel. NOrmandy 5-3500

Cedar Rapids, Iowa

4401 Sixth St. Road, S.W.
P.O. Box 589
Tel. EMpire 5-6921

Charlotte 6, N. C.

1315 No. Graham St.
P.O. Box 2005
Charlotte 1, N. C.
Tel. EDison 4-2851

Columbus 4, Ohio

3700 Sullivant Ave.
P.O. Box 2797
Tel. BRoadway 9-7392

Dallas 15, Tex.

1809 South Lamar St.
P.O. Box 5145
Dallas 22, Tex.
Tel. RIVERSide 2-3413

Denver 16, Colo.

4233 East 46th Ave.
P.O. Box 5028
Denver 17, Colo.
Tel. FLorida 5-4481

Des Moines 16, Iowa

1901 East University Ave.
P.O. Box 1437
Des Moines 5, Iowa
Tel. AMherst 6-1327

Fargo, N. Dak.

4501 West Main Ave.
P.O. Box 591
Tel. 235-6436

Harrisburg, Pa.

1017 Maclay St.
P.O. Box 1357
Tel. CEdar 8-5277

Houston 11, Tex.

4619 Navigation Blvd.
P.O. Box 1425
Houston 1, Tex.
Tel. WALnut 3-9754

Indianapolis 7, Ind.

1065 W. Washington St.
Tel. MELrose 9-1491

Jackson 1, Miss.

210 South Lamar St.
P.O. Box 1073
Tel. 354-5507

Jacksonville 9, Fla.

1986 West Beaver St.
P.O. Box 2020
Jacksonville 3, Fla.
Tel. ELgin 6-8451

Kansas City 15, Kans.

3201 McCormick Road
Tel. FINley 2-7200

Lansing 6, Mich.

1800 N. Grand River Ave.
P.O. Box 1316
Lansing 4, Mich.
Tel. IVanhoe 5-2215

Lexington, Ky.

1105 Eastland Drive
P.O. Box 481
Tel. 2-6008

Little Rock, Ark.

3601 W. 65th St.
P.O. Box 2541
Tel. LOcust 5-5576

Los Angeles, Calif.

530 N. Baldwin Park Blvd.
P.O. Box 2147
City of Industry, Calif.
Tel. YOOrtown 3-271

Madison 4, Wis.

2320 Darwin Road
P.O. Box 1111
Madison 1, Wis.
Tel. CHerry 9-2181

Mason City, Iowa

25 Nineteenth St., S.W.
P.O. Box 201
Tel. 423-6513

Memphis 6, Tenn.

237 West Olive Ave.
P.O. Box 2864
Memphis 2, Tenn.
Tel. WHitehall 2-3261

Oakland 8, Calif.

2855 Cypress St.
P.O. Box 4676
Oakland 23, Calif.
Tel. GLencourt 2-2828

Oklahoma City 8, Okla.

5125 W. Reno Ave.
P.O. Box 1337
Oklahoma City 1, Okla.
Tel. WIndsor 6-2687

Omaha, Nebr.

1000 South Main St.
P.O. Box 588
Council Bluffs, Iowa
Tel. 345-8200

Peoria, Ill.

407 Rock Island Ave.
P.O. Box 1019
Tel. 685-7687

Pittsburgh, Pa.

1000 Ferry St.
Leetsdale, Pa.
Tel. POplar 6-7600

Portland 22, Oreg.

2001 S.E. Harvester Drive
Tel. OLive 4-5481

Richmond 30, Va.

1905 Westmoreland St.
P.O. Box 6857
Tel. ELgin 5-7907

St. Louis, Mo.

5902 No. Lindbergh Blvd.
Hazelwood, Mo.
Tel. PErshing 1-0430

St. Paul 14, Minn.

2572 University Ave.
Tel. MIDway 6-7301

Salt Lake City 15, Utah

1901 South 2nd West St.
P.O. Box 660
Salt Lake City 10, Utah
Tel. HUnter 6-8731

Sioux Falls, S. Dak.

1100 W. Delaware St.
P.O. Box 867
Tel. EDison 4-3661

Spokane 3, Wash.

715 East Sprague Ave.
P.O. Box 223
Spokane 10, Wash.
Tel. MADison 4-9271

Springfield, Mass.

P.O. Box 514
Westfield, Mass.
Tel. LOgan 8-8651

Syracuse 3, N. Y.

210 Teall Avenue
P.O. Box 979
Syracuse 1, N. Y.
Tel. GRANite 4-2923

Wichita 10, Kans.

410 E. 37th St. North
P.O. Box 1720
Wichita 1, Kans.
Tel. TEMple 8-1495

INTERNATIONAL HARVESTER COMPANY • 180 NORTH MICHIGAN AVENUE • CHICAGO 1, ILLINOIS, U.S.A.
1-15-63.